

Minitron

Operating manual



Minitron – Rel. 2.2

Incubator shaker

FW: 3.2

Doc-ID: D008, 1, en_GB – Original

Art. 7000914

More information about the product is
available online at:

www.infors-ht.com/en/minitron



INFORS HT

Headoffice, Switzerland

Rittergasse 27

CH-4103 Bottmingen

T +41 (0)61 425 77 00

info@infors-ht.com

service@infors-ht.com

Supplemental directives

About this Manual



This manual enables the safe and efficient handling of the device. All the information and instructions in this operating manual comply with the current standards, legal regulations and the latest technological developments.

This operating manual is a component part of the device. It must be kept near the device unit and be accessible to staff at all times. All persons working on or with the device must read the operating manual thoroughly and fully understand its contents before beginning any work. Adhering to all the safety notes and operating instructions in this manual is essential to ensure that work is carried out safely.

The scope of delivery may differ from the explanations, descriptions and figures in this operating manual due to special designs, additional options specified on ordering and the latest technical/mechanical modifications.

This manual contains illustrations to aid general understanding. These may differ from the actual device as supplied.

Customer Service and Services

The customer service of the manufacturer or the local licensed dealer is at your disposal for technical advice and specialist enquiries (contact details see → <https://www.infors-ht.com/en/contact/>). Due to their familiarity with the potential applications of the device, the Customer Service team is able to provide information on whether the unit can be used for a specific application or modified to handle the planned process.

Declaration of Conformity

The device meets the general requirements of the following standards:

- Machinery Directive 2006/42/EC
- EMC Directive 2014/30/EU

The declaration of conformity in the sense of the Machinery Directive, Annex II 1 A is attached to the operating manual.

Table of contents

Table of contents

1	Overview of the Device	9
1.1	Basic Unit	9
1.2	Parameters	11
1.3	Operating and Display Elements	12
1.3.1	Operating Elements	13
1.3.2	Display Elements	15
2	Safety and Responsibility	17
2.1	Explanation of Special Displays	17
2.1.1	Warning Messages	17
2.1.2	Other Messages	17
2.2	Intended Use, Incorrect Use and Misuse	18
2.3	Cultivation Vessels to be Used	19
2.4	Qualified Personnel	20
2.4.1	Operator	20
2.4.2	Technician	21
2.4.3	INFORS HT Service Technician or Licensed Dealer	21
2.5	Unauthorised Persons	21
2.6	Responsibility of the Provider	21
2.7	Residual Risks	22
2.8	Safety Features	24
2.9	Warning Symbols on the Device	25
2.10	Declaration of Decontamination	26
3	Setup and Function	27
3.1	Standard Functions	27
3.1.1	Shaking Function	27
3.1.2	Temperature Control (Heating)	28
3.2	Connections and Interfaces	29
3.2.1	Mains Connection	29
3.2.2	Alarm Connection	29

Table of contents

3.2.3	Ethernet Interface.....	30
3.2.4	USB Connection.....	30
3.3	Openings.....	31
3.3.1	Discharge Outlet.....	31
3.3.2	Air Vents.....	31
3.3.3	Ventilation Opening.....	32
3.4	Working Light.....	32
3.5	Substructure.....	32
3.6	Operating and Display Elements.....	35
3.6.1	Power Switch.....	35
3.6.2	Operating Panel.....	35
3.7	Markings on the Device.....	35
3.7.1	Identification Plate.....	35
3.7.2	Identification of the Throw.....	36
4	Options.....	37
4.1	Cooling.....	37
4.1.1	Setup and Function.....	37
4.1.2	Operating the Cooling System.....	37
4.2	Hygienic Humidity Control (HHC).....	38
4.2.1	Setup and Function.....	38
4.2.2	Connection Conditions.....	40
4.2.3	Operating the Humidity Control.....	40
4.3	CO ₂ Control.....	41
4.3.1	Safety Notes.....	41
4.3.2	Setup and Function.....	42
4.3.3	Connection Conditions.....	42
4.3.4	Operating the CO ₂ Control.....	43
4.4	Removable Shelf.....	43
4.5	Darkening.....	44
4.6	Analogue Output.....	44
4.6.1	Setup and Function.....	44
4.6.2	Connection Assignment.....	44

Table of contents

4.7	Cable Pass-through.....	45
4.7.1	Setup and Function.....	45
4.7.2	Using the Cable Pass-through.....	46
5	Accessories.....	48
5.1	Trays.....	48
5.1.1	Universal Table Tray.....	49
5.1.2	Tray with Steel Clamps.....	50
5.1.3	Tray with Pin Holders.....	51
5.1.4	Tray with Clamping Assembly.....	52
5.1.5	Tray with Sliding Bars.....	54
5.1.6	Tray with Sticky Stuff.....	55
5.2	Clamps and Other Holders.....	58
5.2.1	Clamps.....	58
5.2.2	Test Tube Holder.....	60
5.3	Box for Microtitre Plates.....	60
5.4	Profibus DP and Modbus TCP Gateways.....	63
5.5	eve®.....	65
6	Installation and Commissioning.....	66
6.1	Operating Conditions at the Installation Location.....	66
6.2	Requirements for the Mains Connection.....	67
6.3	Minimum Distances to the Device.....	67
7	Operation.....	70
7.1	Switching the Device on.....	70
7.2	Loading the Device.....	70
7.2.1	Opening the Door.....	70
7.2.2	Inserting and Removing the Tray.....	71
7.2.3	Mounting the Holders.....	72
7.2.4	Tips & Tricks for Loading the Tray.....	74
7.3	Setting, Activating and Deactivating Parameters.....	75
7.4	Timer Function.....	76
7.4.1	Overview.....	76
7.4.2	Programming Timer.....	78

Table of contents

7.4.3 Starting the Timer..... 80

7.4.4 Viewing and Changing Timer Settings..... 81

7.4.5 Stopping the Timer..... 82

7.5 Using eve® to Operate the Device..... 83

7.6 Settings Menu (Option Function)..... 85

7.6.1 Opening the Settings Menu..... 85

7.6.2 Using the Settings Menu..... 85

7.6.3 Settings..... 86

7.7 Switching off the Device..... 90

7.8 Behaviour in Case of a Power Interruption..... 90

8 Rectifying Faults..... 91

8.1 Alarm Messages..... 91

8.1.1 Parameter Alarms (*HIGH/LOW*)..... 91

8.1.2 Device-specific Messages..... 92

8.2 Error Messages..... 93

8.3 Fault Tables..... 95

8.4 Replacing Device Fuses..... 99

8.5 Returning for Repair..... 100

9 Cleaning and Maintenance..... 101

9.1 Maintenance..... 101

9.2 Cleaning and Disinfection..... 102

9.2.1 Cleaning the Device..... 102

9.2.2 Disinfecting the Device..... 103

9.2.3 Cleaning and Disinfecting the Base Tray..... 103

10 Transport and Storage..... 105

10.1 Transport..... 105

10.2 Storage..... 105

11 Disassembly and Disposal..... 106

11.1 Disassembly..... 106


11.2 Disposal..... 106

Table of contents

12 Technical Data	108
12.1 Dimension Drawings	108
12.2 Specifications of the Basic Unit	109
12.2.1 Weight	109
12.2.2 Dimensions	109
12.2.3 Electrical Connection and Power Values	110
12.2.4 Connections and Interfaces	110
12.2.5 Materials	111
12.2.6 Emissions	111
12.2.7 Operating Conditions	112
12.2.8 Fire Protection Class and Protection Type	112
12.2.9 Operating and Auxiliary Materials	112
12.3 Specifications of the Standard Parameters	113
12.3.1 Rotation Speed Parameter (Shaker Drive)	113
12.3.2 Temperature Parameter	115
12.3.3 Ideal Loading Weights	116
12.4 Specifications of the Options	117
12.4.1 Cooling	117
12.4.2 Hygienic Humidity Control (HHC)	117
12.4.3 CO ₂ Control	119
13 EU Declaration of Conformity	121
14 Index	123

1 Overview of the Device

1.1 Basic Unit



- | | |
|---|--|
| 1 Casing | 10 Table |
| 2 Grip recess for opening the door | 11 Pt100 temperature sensor (+ optional sensors) |
| 3 Axial fans | 12 Connection for the external alarm (behind the door) |
| 4 Door with window (opening to the right) | 5 USB connection (only for service purposes) |
| 5 Display and operating elements | 14 CO ₂ connection (CO ₂ IN, optional) |
| 6 Power switch (<i>POWER</i>) | 15 Ethernet interface (<i>LAN</i>) |
| 7 Discharge outlet | 16 Air vents |
| 8 Rubber feet | 17 Mains connection with slot for fuses (<i>MAINS</i>) |
| 9 Door heating | |


Short Description

The Minitron incubator shaker is used to cultivate microorganisms or cell cultures in a laboratory environment. The basic version of the device is fitted with a shaker drive and a heater. Depending on which version of the device you have bought, it will come with either a 25 mm or 50 mm throw.

The device can be operated either locally, using the operating panel on the front of the device, or remotely, using a computer connected to the device via the Ethernet interface.

Overview of the Device

Stacking Devices



If necessary, two units can be stacked to save space. In a stack of two, the rubber feet must be replaced by the stable base (height: 130 mm). Devices can also be stacked subsequently but stacking must be performed by the manufacturer's qualified expert personnel or persons authorised by the manufacturer.

If stacked devices are operated, you have to keep in mind that the maximum permissible rotation speed is limited for the top unit in the stack. For a detailed description of the technical data and possible maximum rotation speeds of stacked devices, see → Chapter 12.3.1 'Rotation Speed Parameter (Shaker Drive)' on page 113.

Overview of the Options

The following options are available for adapting the device to different usage scenarios:

Option	Additional information
Cooling	→ Chapter 4.1, page 37
Hygienic Humidity Control (HHC)	→ Chapter 4.2, page 38
CO ₂ control	→ Chapter 4.3, page 41
Removable shelf	→ Chapter 4.4, page 43
Darkening	→ Chapter 4.5, page 44
Analogue output	→ Chapter 4.6, page 44
Cable pass-through	→ Chapter 4.7, page 45


Overview of the Device

1.2 Parameters

Parameter	Display	Unit	Setting range	Option	Additional information
Temperature	<i>Temp.</i>	°C	4.0 to 65.0	No	The temperature that can actually be achieved depends on a variety of factors (e.g. the ambient temperature around the device, the ventilation and the temperature of the other devices in the stack) (→ Chapter 12.3.2, page 115).
Rotation speed	<i>RPM</i>	min ⁻¹	20 to 400	No	The maximum permissible rotation speed depends on the throw, the position of the device in a stack, and the load on the tray (mass). (→ Chapter 12.3.1, page 113).
Humidity	<i>Humidity</i>	%	20.0 to 85.0	Yes	While the evaporator of the humidification system is heating up and until the “Temperature” parameter has reached the set-point, <i>HEAT</i> is displayed (alternating with the current value).
CO ₂ concentration	<i>CO₂</i>	%	0.1 to 20.0	Yes	

Overview of the Device

1.3 Operating and Display Elements




- 1 Status display (PIN function, remote control of the device)
- 2 Upper view box: Parameters target/actual values (Temperature, CO₂)
- 3 Lower view box: Parameters target/actual values (Rotation speed, humidity)
- 4 View box for timer function and error messages

- 5 Upper control panel: Setting the parameters (Temperature, CO₂)
- 6 **Select** key
- 7 Lower control panel: Setting the parameters (Rotation speed, humidity)
- 8 **TIMER** key
- 9 **OPTION** key

1.3.1 Operating Elements

Overview



The device is controlled via keys in the operating section. The keys are colour-coded based on their function:

- Black: Setting keys
- Blue: Timer selection key
- Orange: Parameters and settings selection key








The black setting keys exist in duplicate form. The upper setting keys control the parameters in the upper view box, the lower setting keys control the parameters in the lower view box.

i The sensor-controlled soft-touch keys are located behind the glass cover and only need to be pressed lightly.
The device can also be operated with laboratory gloves.

i If the interior lighting is activated, it switches on automatically as soon as any key is pressed. After 2 Minutes, it turns off again automatically.


Overview of the Device

Function

Operating element	Designation	Function
	Select	The Select key is used to select the parameters (also within the Timer function). The key is also used to exit the timer overview and the settings menu.
	TIMER	The TIMER key is used to open the Timer overview and select the phases within timer programming. For more information, see → Chapter 7.4.1 'Timer Function' on page 76.
	OPTION	The OPTION key is used to open the Settings menu. This menu enables you to adjust the main device settings. Pressing the key again closes the Settings menu. For more information, see → Chapter 7.6.1 'Settings Menu (Option Function)' on page 85.
	SET	After pressing the SET key, you can enter the values for the selected parameter.
	Plus	Use the Plus key to increase values. When you hold down the key, the display runs up the specified value range in increasingly large intervals. The key is used for navigation in the Settings menu.
	Minus	Use the Minus key to decrease values. When you hold down the key, the display runs down the specified value range in increasingly large intervals. The key is used for navigation in the Settings menu.
	ON/OFF	You can use the ON/OFF key to switch on or off the selected parameter, a setting in the Settings menu or the timer.

1.3.2 Display Elements

Parameter



The following parameters are displayed in the upper view box:

- Temperature (*Temp.*)
- CO₂ concentration (*CO₂*, optional)

The following parameters are displayed in the lower view box:

- Rotation speed (*RPM*)
- Humidity (*Humidity*, optional)

Depending on their status, the parameters are displayed in different colours:

- Black: The parameter is activated.
- Grey: The parameter is deactivated.
- Orange: The parameter is in programming mode, i.e. the setpoint can be set and the parameter can be activated or deactivated.

Parameter-specific Displays

Display	Meaning
SETPOINT	The parameter is in programming mode (the setpoint can be set and the parameter can be activated or deactivated).
OFF	The parameter is deactivated.
REMOTE	The parameter is controlled by a software (e.g. eve [®]) connected to the device.
REMOTE OFF	The parameter was deactivated by a software (e.g. eve [®]) connected to the device by sending setpoint 0. <i>REMOTE OFF</i> is displayed until a new setpoint is set on the device.
HIGH LOW	The actual value of the parameter deviates significantly from the setpoint.
MAX <small>°C Temp.</small>	The possible setpoints for the "Rotation speed" and "Temperature" parameters can be restricted in the Settings menu. If you try to enter a higher or lower value, <i>MAX</i> or <i>MIN</i> is displayed.

Overview of the Device

Status Displays

Symbol	Meaning
	The control panel is locked with a PIN. If you try to make a setting, a PIN prompt appears. Once you enter the correct PIN, the symbol disappears.
	<p>The device is connected to external software (e.g. eve®).</p> <ul style="list-style-type: none"> Both arrows are greyed out. The connection to the software has been established (IP is known), but there is no communication. The up arrow is orange, the down arrow is greyed out. The software is reading values but unable to send setpoints. The device is in "Read only" mode Both arrows are orange: The software is reading values and able to send setpoints. The device is in "Read & write" mode. <p>For more information, see ➔ 'Ethernet Connection' on page 87.</p>

Alarms, Error and Warning Displays

INFO: RESTARTED

Device restarted automatically after power loss with saved parameter setpoints.

Underneath the parameter displays, there is a separate field in which alarms and error messages are displayed in red info boxes. The info boxes describe the alarm or the error (➔ Chapter 8 'Rectifying Faults' on page 91).

Timer Display

PHASE 1 01:43:02

PHASE 2 04:48:00

If the timer function is active, the two phases and the running time of the phases are shown on the lower side of the display (➔ Chapter 7.4.1 'Timer Function' on page 76).

2 Safety and Responsibility

This chapter contains general information on safety when using the device. In the remaining chapters, warning messages are used only to highlight particular hazards directly arising from the actions being described.



It is essential to read the operating manual carefully – especially this chapter and the warning messages in the text – and to follow the instructions therein.

This chapter also refers to areas that are the responsibility of the provider due to certain risks arising from particular applications for which the device is used deliberately and with full awareness of the associated risks.

2.1 Explanation of Special Displays

2.1.1 Warning Messages

Warning messages in this manual are indicated by a coloured bar and begin with a signal word that signifies the degree of the hazard.

WARNING

The signal word “WARNING” indicates a potentially dangerous situation that may result in severe or fatal injuries if not avoided.

CAUTION

The signal word “CAUTION” indicates a potentially dangerous situation that may result in minor injuries if not avoided.

NOTICE

The word “NOTICE” on a blue bar indicates a situation that may result in significant damage to property if not avoided.

2.1.2 Other Messages



Texts that are marked in this way provide useful tips and recommendations for ensuring efficient, fault-free operation of the device.

Safety and Responsibility

2.2 Intended Use, Incorrect Use and Misuse

Intended Use

The device is designed to be used as an incubator shaker for cultivating microorganisms or cell cultures under the following conditions:

- Cultivation of non-pathogenic microorganisms or cell cultures of risk category 1 in a biotechnology lab of biological protection level 1.
- Cultivation of pathogenic microorganisms or cell cultures of risk category 2 in a biotechnology lab of biological protection level 2.

When using the device in protection level 2, personnel are responsible for taking appropriate protective measures to ensure that organisms cannot escape uncontrollably due to flask breakage, unintentional detaching of the sterile seal or similar.

WARNING

The device is designed and built exclusively for the intended use described above.

Each instance of non-conventional use of the device is considered incorrect use and may lead to dangerous situations.

Intended use also includes following all the instructions in this manual, especially those relating to:

- The installation site
- Use of suitable cultivation vessels
- Personnel qualifications
- Permissible parameter setpoints
- Correct operation and maintenance

Incorrect Use/Misuse

Any failure to observe the requirements specified in this manual shall be deemed incorrect use, in particular, use of inappropriate cultivation vessels and/or unsuitable holders at rotation speeds that are too high.

Any use of the device outside the scope of the intended use as described above shall be deemed misuse. This also applies to applications for which the device is not designed, especially the following:

Safety and Responsibility

- The device is not protected against explosions. Use and manufacture of explosive gases as well as operating the device in the Ex area are therefore not permitted.
- The device is not designed to sufficiently protect the personnel if pathogenic organisms escape uncontrollably. Cultivation of pathogenic organisms of risk categories 3 and 4 is therefore not permitted.

To use the device for special applications not covered by conventional, intended use, the device must be modified and certified accordingly by the manufacturer.

Any use of the device outside of a biotechnology laboratory, i.e. in any environment in which the conditions required for the safety of the personnel cannot be met or cannot be met to their full extent, shall also be deemed misuse.

2.3 Cultivation Vessels to be Used

! NOTICE

Significant forces are applied to cultivation vessels, in particular in case of large vessels and high rotation speeds. Use of unsuitable or defective cultivation vessels can lead to glass breakage and therefore damage to property.

Approved Cultivation Vessels

The device has been designed for use with the following vessels using the holders designed specifically for them:

- Erlenmeyer flasks up to 5000 mL made of borosilicate glass (e.g. Schott Duran®) or high-grade plastic, such as polycarbonate (e.g. Corning®) etc.
- Fernbach flasks up to 3000 mL made of borosilicate glass (e.g. Schott Duran®) or high-grade plastic, such as polycarbonate (e.g. Corning®) etc.
- Other vessels with the holders designed for them:
 - Test tubes
 - Centrifuge tubes
 - Microtitre plates
 - Deep-well plates

To avoid the vessels coming out of the clamps at very high rotation speeds, they might have to be secured using cable ties underneath the springs or some other suitable measure.

Safety and Responsibility

Cultivating Organisms of Risk Category 2

When cultivating pathogenic organisms of risk category 2, special measures must be taken to stop the organisms from escaping. The user is responsible for this.

When using the device under protection category 2, stainless steel clamps of the correct size must be used to affix the flasks. Due to limited resistance to disinfectants as well as the risk of unintentional detaching of flasks, Sticky Stuff adhesive matting is not suitable for this purpose.

We further recommend using disposable plastic flasks with screw tops and filter membranes. We recommend using adhesive tape to secure the top plate against coming off unintentionally. Using glass flasks with cotton wool or paper plugs is not sufficiently safe.

Trays with Sticky Stuff



For trays with Sticky Stuff, special provisions apply in relation to maximum permitted rotation speeds. These must be observed to prevent cultivation vessels from detaching.

For more information, see → Chapter 5.1.6 'Tray with Sticky Stuff' on page 55.

2.4 Qualified Personnel

2.4.1 Operator

The operator operates the device in the context of the intended use. Only persons who have been trained for working in a biotechnology laboratory can be considered for the role of operator. These include, for example:

- Process technicians in the fields of biotechnology and chemistry
- Biotechnologists (biotechnicians)
- Chemists with a specialisation in biochemistry; chemists in the field of organic chemistry or biochemistry
- Life scientists (biologists) with special education in cytology, bacteriology, molecular biology, genetics, etc.
- Lab assistants (lab technicians) from various fields

To be allowed to operate the device, the operator must have received thorough training and have read and understood the operating manual.

The operator must be informed in a training session provided by the provider of the tasks delegated to the operator and the potential risks of improper conduct. Tasks that go beyond the scope of operation

under normal conditions may only be performed by the operator if this is specified in the manual and the provider has explicitly entrusted said tasks to the operator.

Persons who are undergoing training or apprenticeships are only permitted to use the device under supervision and in accordance with the instructions of a trained and qualified technician.

2.4.2 Technician

The technician is an individual who, by virtue of their relevant professional education, training and/or experience, is competent to identify risks and prevent hazards arising from the use of the device. The technician is familiar with the environment in which they are operating and knows the relevant standards and regulations.

Technicians include, for example, the following groups of people:

- Qualified electricians
- Decontamination specialists
- Disassembly, disposal and recycling specialists

2.4.3 INFORS HT Service Technician or Licensed Dealer

Certain work may only be performed by the manufacturer's skilled personnel or by skilled personnel authorised by a licensed dealer. Other persons are not authorised to perform this work.

2.5 Unauthorised Persons

The term "unauthorised persons" applies to all persons who can access the work area but are not qualified to use the device in accordance with the aforementioned requirements.

Unauthorised persons are not permitted to operate the device or use it in any other way.

2.6 Responsibility of the Provider

Provider

The term "provider" applies to all persons who are responsible for making the device and the necessary infrastructure available. The provider bears a special level of responsibility with regard to the processes and the qualification and safety of the operators.

Safety and Responsibility

Provider Obligations

The device is used for industrial and scientific purposes. As such, the provider of the device is individually liable with regard to the legal requirements relating to occupational health and safety in a biotechnology laboratory. In particular:

- The provider is responsible for ensuring that the work and environmental regulations applicable in a biotechnology laboratory are observed.
- The provider must ensure that the device remains in safe and proper working condition throughout its entire term of use.
- The provider must ensure that all safety devices are fully functional and not disabled.
- The provider must ensure that the device is only operated by qualified personnel, and that said personnel receive sufficient training.
- The provider must ensure that the protective equipment required for working with the device is available and worn.
- The provider must ensure that this operating manual remains in the immediate vicinity of the device throughout its entire term of use.

2.7 Residual Risks

This chapter residual risks that are always present when using the device in accordance with normal, intended use.

Electric Current



The device is operated electronically. There is an immediate risk of fatal injury if contact is made with live parts. The following points must be observed in order to avoid the risk of fatal injury:

- In case of damage to insulation, disconnect the device from the power supply immediately and arrange for it to be repaired.
- Disconnect the device from the power supply before commencing any work on the electrical components.
- Always use qualified electricians for any work on the electrical components.
- Disconnect the device from the power supply before commencing any maintenance, cleaning or repair work.
- Do not bypass any fuses or take them out of operation.
- When replacing fuses, ensure they have the correct number of Amperes.
- If the power cable is defective, replace it with a power cable of the same type.
- Keep moisture away from live parts. It could cause a short circuit.
- Never remove covers from live parts.

Moving Parts



Moving parts are a general hazard posed by the device because body parts can be pinched or scratched when one is not careful.

However there is no risk of clothing or body parts being pulled into the device. The risk that fingers are pinched has been minimised by means of a sufficient distance between the tray and the casing and a stop mechanism that stops the shaker drive when the door is opened. Nonetheless, the cultivation flasks must only be moved when the table has come to a complete standstill.

Hot Surfaces



For applications that are performed with temperatures over 55 °C, there is a risk of burns on hot surfaces in the interior, on the tray or on the cultivation vessels.

For applications with temperatures of above 55 °C, wear heat-resistant protective gloves.

Dangerous Gases



The use or production of dangerous – i.e. toxic or asphyxiant – gases entails a significant health risk, especially in small rooms. To prevent high emissions of dangerous gases, the following measures must be taken:

- The gas connections on the device must be checked before any cultivation using dangerous gases are initiated.
- Check the seals on the device at regular intervals and replace them if necessary.
- Check gas-carrying hoses for leaks at regular intervals.

Flammable or Explosive Substances



The use or production of flammable or explosive substances does not fall under the intended use, as the device is not explosion-proof. If the provider intends to use the device for such applications, it is essential to check the suitability of the device with the relevant local authorities.

There is a risk of explosions when using impure process gases: You must therefore only use process gases without impurities.

Corrosive or Toxic Substances



The use or production of corrosive or toxic substances entails a significant health risk. As such, special measures must be taken to protect personnel for such applications.

Since the device is used deliberately for such applications, it is the responsibility of the personnel to ensure that they have sufficient protection.

Safety and Responsibility

Pathogenic Organisms



The device is not approved for cultivation of pathogenic organisms of risk categories 3 and 4. In the context of intended use, it is nonetheless possible for pathogenic organisms and viruses to be cultivated. Contact with pathogenic organisms bears a significant health risk. Therefore, personnel are responsible for providing adequate protection.

Accessories and Spare Parts




Incorrect spare parts, imitations or spare parts that have not been authorised by the manufacturer and unauthorised accessories represent a significant safety risk. As such, we recommend procuring all spare parts and accessories from a licensed dealer or directly from the manufacturer.

2.8 Safety Features

The device comes with the following safety features:

Device Fuses



The device is protected from impermissibly high power input by two fuses. The slot for the fuses is directly above the mains connection on the right side of the casing underneath the *MAINS* label. For descriptions of which fuses to use for which device type see [Chapter 12.2.3 'Electrical Connection and Power Values'](#) on page 110.

Overheating Shut-down



The heating of the device is protected against overheating by a temperature limiter. This triggers as soon as the temperature on the heating element exceeds the maximum allowed value and immediately turns off the heating.

Door Monitoring

The position of the door is monitored electronically. If the door is opened, all dangerous movements (shaker drive and fans) are stopped immediately. As soon as the door is closed again completely, the shaker drive and fans restart automatically.

2.9 Warning Symbols on the Device

The following warning symbols (stickers) are placed on the device:

Warning symbol	Position	Meaning
	On the housing of the optional humidity control on the rear of the device.	Observe the instructions in the operating manual when connecting the humidity control to ensure compliance with the required water quality. For information regarding the required water quality, see → Chapter 12.4.2 'Hygienic Humidity Control (HHC)' on page 117.
	On the device casing next to the power plug.	Danger due to electrical current. The device covers may only be opened by qualified electricians or authorized service technicians. Switch off the device and pull out the mains plug before starting any work on the electrical system.

 **WARNING**

Illegible or missing warning symbols on the device will lead to the personnel being exposed to risks that the warning symbols in question were designed to make them aware of.

It is the provider's responsibility to ensure that all the stickers with warning symbols on the device are always intact.

Safety and Responsibility

2.10 Declaration of Decontamination

When returning the device for repair, disassembly or disposal, a legally compliant declaration of decontamination is required for the safety of all involved and due to legal requirements. The following must be observed if this is the case:

- The device, component or accessory which is to be repaired must be entirely decontaminated before being sent to the manufacturer.
- The provider is therefore required to completely and truthfully fill out a declaration of decontamination, and have it signed by the person responsible.
- The declaration of decontamination must be affixed on the outer packaging in which the device is sent back.
- These forms can be obtained from the licensed dealer or the manufacturer.




If the return shipment is not accompanied by a signed and complete declaration of decontamination or it is not affixed to the outer packaging, the shipment will be returned unopened to the sender at their expense (see also T&C).

3 Setup and Function

3.1 Standard Functions

3.1.1 Shaking Function

Mechanics




The shaking table moves in a circular movement. It is driven by an electric motor, which is connected to the device’s flywheel by a drive belt. To prevent injuries and facilitate loading and unloading, the drive is switched off automatically as soon as the door is opened.

In the centre, there is an eccentrically rotating shaft with the flange (1) for receiving the table. The device is available with a 25 mm or 50 mm throw.

The image shows the counterweight (2) for balancing the mass on the table. In the corners of the interior, there are four bearings (3) for stabilising the table.

Shaking Table



The shaking table is used to hold the 48 x 42 cm (type N) tray, various versions of which are available. Bars on the side (2), a stop at the back (1) and two tapered plugs (3) ensure that the tray is positioned correctly.

The shaking table is connected to the drive hub (4) by means of four hexalobular socket screws. To clean the base tray, the table can be removed by loosening the four screws.

Operation



The “Rotation speed” parameter (*RPM*) is operated via the operating panel. For information on how to set and activate the parameter, see → Chapter 7.3 ‘Setting, Activating and Deactivating Parameters’ on page 75.




The permissible load weights depend on the position of the device in the stack, the shaking throw and the shaking speed (→ Chapter 12.3.1 ‘Rotation Speed Parameter (Shaker Drive)’ on page 113).

Setup and Function

3.1.2 Temperature Control (Heating)

Function



The temperature in the incubation chamber is regulated using a Pt100 temperature sensor (1) with a PID controller. Three axial fans (2) ensure constant air circulation, and keep the temperature distribution in the incubation chamber as constant and gradient-free as possible. A heating element is located on the right-hand side of the device behind the sheet metal cover to heat the air in the incubation chamber. To reach temperatures below the ambient temperature, the device can be fitted with an optional cooling system.



The only purpose of the temperature sensor is to measure the temperature of the air in the incubation chamber. Do not remove the temperature sensor from the holder and immerse it in the liquid in the flask.

Operation



The "Temperature" parameter (*Temp*) is operated via the operating panel. For information on how to set and activate the parameter, see → Chapter 7.3 'Setting, Activating and Deactivating Parameters' on page 75.

3.2 Connections and Interfaces

3.2.1 Mains Connection



The mains connection is located on the right-hand side of the device. Three different versions of the device are available for different mains voltages:

- 230 V 50 Hz
- 230 V 60 Hz
- 115 V 60 Hz


Two device fuses immediately adjacent to the mains connection protect the device from impermissibly high power input.

The country-specific power cable required for connecting the power supply is included in the device's scope of delivery. If the power cable is defective, replace it with a power cable of the same type.

Prior to connecting the device, make sure that the voltage values of the device match those of the local mains voltage. The mains connection must be easily accessible at all times so that the device can be disconnected from the power supply quickly in case of an emergency.


For information on the electrical connection values, see → Chapter 12.2.3 'Electrical Connection and Power Values' on page 110.

3.2.2 Alarm Connection




On the right side of the housing, there is a socket (stereo jack, 3.5 mm) for connecting the device to an alarm system. It is labelled *EXTERNAL ALARM*. The socket is designed for a maximum of 34 V AC/DC, 1 A. The alarm relay is activated permanently as long as the alarm is active.

Allocation of contacts:




- 1 COM (common)
- 2 NC (normally closed)
- 3 NO (normally open)



Setup and Function

3.2.3 Ethernet Interface



The device has an Ethernet interface (RJ45 socket). This is located on the right side of the device. The Ethernet interface can be used for the following purposes:

- Integration of the device into a network to control the device via eve® the bioprocess platform software.
- Connection of the device to a PLC to control the device via a SCADA system. Depending on the protocol used, this requires either the Profibus DP or Modbus TCP gateway (➔ Chapter 5.4 'Profibus DP and Modbus TCP Gateways' on page 63).
- Control of the device via a laboratory management or monitoring system from a third-party manufacturer. For this purpose, a driver must be developed which translates the protocol used for the external software. The necessary documentation for the communication protocol can be ordered from INFORS HT.

The following data and states are transmitted via the Ethernet interface:


- From the device to the SCADA/bioprocess software: setpoints and actual values of the parameters as well as the status of the door and PIN function
- From the SCADA/bioprocess software to the device: sending new setpoints



Alarms and error messages are not transmitted via the Ethernet interface. Alarm limits can be defined either in eve® or in the SCADA system, depending on the application.

For more information on using the Ethernet interface, see ➔ Chapter 7.5 'Using eve® to Operate the Device' on page 83.


3.2.4 USB Connection



The USB connection on the right side of the operating panel is reserved for service purposes and has no function in normal operation.

3.3 Openings

3.3.1 Discharge Outlet



For draining spilled liquids, cleaning agents or accumulated condensation water, there is a discharge outlet at the bottom, almost in the middle of the left side of the casing.


The opening is sealed with a yellow plug on delivery. A hose nozzle (1/4 inch) for connecting a hose (Ø 10 mm) is provided.



In case of large fill volumes, we recommend installing the discharge hose to avoid the bearings coming into contact with liquid if a flask breaks.

If safety requirements must be met, e.g. when working with genetically modified organisms, the discharge hose must lead to a suitable, sealed receptacle. One example of such a receptacle would be an empty chemical container sealed with foil.


3.3.2 Air Vents




The device has several air vents. When setting up the device, you must ensure that these air vents remain unobstructed (keeping a minimum distance of 80 mm to walls or objects on either side) in order to ensure that the exit gas can be extracted without obstruction and none of the components overheat.

Setup and Function

3.3.3 Ventilation Opening



An opening for ventilation of the interior is located in the top centre of the rear of the housing. The purpose of ventilation is to supply bacterial cultures with oxygen from the air.



The opening with a diameter of 22 mm is covered by a metal plate with a plug and O-ring (1). The plate can be mounted in two different ways:


- If the plug (1) is facing inwards and the folded parts of the plate (2) are facing outwards, the plate will seal tightly.
- If the plug (1) is facing outwards and the folded parts of the plate (2) are facing towards the device, this results in a ventilation slot.



If the optional "CO₂" and/or "Humidity" parameters are available on the device, the device is delivered with the opening sealed. The subsequent opening of the ventilation can lead to a significantly higher gas consumption in this case.

If the optional parameters "CO₂" and/or "Humidity" are not available, closing the ventilation can lead to a lack of oxygen to the culture and therefore to low growth.

3.4 Working Light



The device features interior lighting. The interior lighting consists of a print with 3 white LEDs, which is installed on the right side of the casing in the recess underneath the fan.

The interior lighting is switched on automatically as soon as a key is tapped or the door is opened. After 2 minutes without input or 2 minutes after closing the door, the lighting switches off again automatically.

In the settings menu (**OPTION** key) the interior lighting can be completely deactivated if necessary.

3.5 Substructure

Different versions of the incubator shaker are available with different substructures:

Rubber Feet



Individual units placed on a table are equipped with a grounding plate with four rubber feet. The rubber feet are firmly screwed to the housing and cannot be adjusted in height. Table models must therefore always be placed on a level surface.

Base, 13 cm




Individual and stacked units can be fitted with a 13 cm base. The base has an adjustable foot that can be used to level the device.

Levelling the Base


To be able to operate the device at very high speeds, it must be absolutely level. Hence, the optionally available base is equipped with a foot that can be levelled. The adjustable foot is located on the front right side of the base.

Setup and Function



- 1 Adjustable foot
- 2 Locknut (SW 19)
- 3 Hexagon for adjusting the foot (SW 14)

To level the base, proceed as follows:



1. ➤ Loosen the locknut (SW 19) on the adjustable foot.
2. ➤ Set the desired height on the hexagon (SW 14) of the foot.
3. ➤ Use a spirit level to check the correct position of the device on all three axes.
4. ➤ Tighten the locknut again.
5. ➤ With the device loaded, increase the rotation speed in increments of 50 min⁻¹. Check and ensure that no vibrations occur.




If you have a stack of 2 units, equally load both units, start them and operate them at increasing rotation speed to test both of them together.

If vibrations occur during this final test, the steps described above have to be repeated until a stable run is achieved throughout the whole range of rotation speed.

If the device is positioned on particularly slippery ground, anti-slip underlay must be placed under all feet. The device can thus be stopped from moving on the floor.

3.6 Operating and Display Elements

3.6.1 Power Switch




The power switch is located on the right-hand side of the device. In addition to normal switching on and off, the power switch also works as an emergency switch.



If the device is switched off, all parameter setpoints remain stored and the device restarts immediately when it is switched on again.

3.6.2 Operating Panel



All device functions can be controlled directly via the operating panel on the front of the device. The operating panel is divided into a display section and an operating section.


- In the display section on the left side, information on actual values and setpoints, run times of the timer function and fault notifications are displayed, among other things.
- The keys in the operating section on the right side can be used to set the parameters and the timer function and adjust the basic settings of the device.

For more information on the display and operating elements on the operating panel, see → Chapter 1.3 'Operating and Display Elements' on page 12.

3.7 Markings on the Device

3.7.1 Identification Plate


Position



The identification plate for identifying the device is located on the right side of the casing, directly above the mains connection.

Setup and Function


Content



The identification plate is designed to allow clear identification of the device. It contains the following information:

- Manufacturer's name
- Designation = category of device
- Type = device type (name)
- S/N = serial number
- Year = year of manufacture
- Mains = nominal voltage and frequency
- Current = power consumption
- Manufacturer's address
- CE marking

3.7.2 Identification of the Throw



At the front left of the table, there is a sticker that identifies the throw (*Throw*) of the device.

4 Options

To adapt the device to the specific usage scenarios, the device can be enhanced with various options. The options can be ordered at the same time as the device or can be fitted at a later stage. For detailed information on the options as well as advice, please contact our customer service.

4.1 Cooling

4.1.1 Setup and Function



For processes that require low temperatures, the device can be equipped with a cooling unit. The cooling unit is installed at the top right (viewed from the front) on the back of the device. The cooling unit can be used to achieve temperatures of up to 16 °C lower than the ambient temperature but no lower than 4 °C.

The refrigerant circulates in a closed circuit which makes the cooling unit mostly maintenance-free.




CAUTION

During operation, the surface of the compressor of the cooling unit reaches temperatures of around 70 °C. Touching the hot surface can result in burns.

However, the compressor is installed in such a way that it normally cannot be touched during operation.

4.1.2 Operating the Cooling System




The cooling system is operated using the “Temperature” parameter (*Temp*). Cooling is activated automatically, if this is necessary to reach the entered setpoint for the temperature.

For information on how to set and activate the parameter, see → Chapter 7.3 ‘Setting, Activating and Deactivating Parameters’ on page 75.

Options

4.2 Hygienic Humidity Control (HHC)

4.2.1 Setup and Function



- 1 Hygienic Humidity Control
- 2 Humidity sensor

Part of the medium can evaporate, in particular in case of small volumes of work (e.g. when using microtitre and deep well plates) and long cultivation processes. To reduce evaporation of the medium, the device can also be fitted with Hygienic Humidity Control. This regulates the humidity in the incubation chamber to a defined setpoint and thus ensures a consistent culture volume.


Humidity control allows both humidification and dehumidification of the air in the incubation chamber.

- **Humidification:**

A controlled water pump feeds water into an evaporator chamber via a feed hose. The water is heated, evaporates and is then fed directly into the incubation chamber. At the same time, a diaphragm pump enriches the steam in the evaporation chamber with ambient air. This has the effect that the air remains above the dew point when entering the incubation chamber. This prevents water from condensing in the incubation chamber.

- **Dehumidification:**

To dehumidify the air in the incubation chamber, ambient air is introduced into the incubation chamber. This reduces the relative humidity in the incubation chamber, that is, the air is dried.



For pumping water and air, as well as for generating steam, the device is equipped with a water pump, air pump and an evaporation chamber. These, as well as the electronics of the humidity control, are located in their own housing at the rear of the device (1) To measure the humidity in the incubation chamber, a humidity sensor is located in the rear wall of the incubation chamber (2).

Notes on Use

Observe the following points when using humidity control:


- Humidity control is optimised for operation at temperatures up to 40 °C.
- The “Temperature” parameter must be activated.
- The air in the incubation chamber is dehumidified by supplying ambient air to the incubation chamber. The lowest possible humidity in the incubation chamber therefore corresponds to the humidity of the ambient air.

Additional Heating Elements

As an additional means of preventing condensation in the incubation chamber, the device is equipped with several heating elements (door heating and door seal heating). These are activated automatically, as soon as humidity control is switched on.

Options

4.2.2 Connection Conditions



Before commissioning the humidity control, the unit must be connected to the water supply. There are two types of water supply:

- Unpressurised from a water tank
- With inlet pressure of max. 2 bar from a pressurised water pipeline

The connection for water supply for humidity control is located at the bottom of the housing and is designed for PTFE hoses with a diameter of 3.2 mm.

! NOTICE

Using tap water can quickly lead to limescale in the vaporiser of the humidification unit, which would affect correct functioning.


Adding detergents, disinfectants or similar chemicals to the water for the hygienic humidity control can damage the device. Only use water without additions, in accordance to the specification.

For an optimal operation, reverse osmosis water with a conductivity of approx. 5 µS/cm is recommended. Ultra-pure water or WFI (water for injection purposes) are also permissible.



If a water tank is used for the water supply, it can be placed either on the device or on the floor during operation. However, during initial commissioning and whenever the supply hose is empty, it is necessary to place the water tank higher than the humidity control housing (e.g. on the device) until the supply hose is completely filled with water. This is necessary because the maximum suction height of the pump is limited when dry.

4.2.3 Operating the Humidity Control



Humidity control is operated using the “Humidity” parameter (*Humidity*).



To prevent condensation on the walls of the interior, the humidity control evaporator is not turned on until the temperature setpoint ($\pm 1^\circ\text{C}$) is reached. After switching on the parameter and reaching the temperature setpoint, it takes approx. 5 minutes for the evaporator to heat up. During this time, the actual value of the humidity and the message *HEAT* are displayed.



If the parameter is constantly in the *HEAT* state, check if the "Temperature" parameter is activated. This must be switched on in order to use humidity control.

For information on how to set and activate the parameter, see → Chapter 7.3 'Setting, Activating and Deactivating Parameters' on page 75.

4.3 CO₂ Control

4.3.1 Safety Notes

CAUTION

During normal operation, small amounts of CO₂ are constantly dissipated into the environment. Leaking CO₂ can lead to discomfort, loss of consciousness or even death by suffocation, especially in small rooms.

- The provider must install a monitoring system that permanently monitors and evaluates the CO₂ concentration in the room.
- If you are using CO₂ control, only operate the device in well-ventilated areas.
- Comply with local health protection laws and regulations in relation to the use of CO₂ and its limits.
- Regularly check the gas pipelines for leaks.




Opening the ventilation opening on the rear of the device can lead to significantly higher gas consumption. We therefore recommend leaving the ventilation opening closed when using CO₂ control.

Options

4.3.2 Setup and Function


Functional Description



The optional CO₂ control makes it possible to enrich the atmosphere in the interior by 0 % to 20 % CO₂. CO₂ control is particularly suited to cultivation of mammalian cells and algae because the CO₂ ensures that the pH value in the culture medium is stable.

The CO₂ supply is regulated with a control valve. Inflow of CO₂ must be ensured using external supply where the pressure can be regulated. On the right side of the housing, there is a hose nozzle for a hose with a diameter of 3 mm to 4 mm to connect the supply.

CO₂ Sensor



The CO₂ sensor for measuring and controlling the CO₂ content is mounted on the right side of the back wall of the incubation chamber.

4.3.3 Connection Conditions

Gas Supply

The in-house CO₂ supply to the device must meet the following requirements:

- Constant inlet pressure not exceeding 0.5 bar (± 0.1)
- Only use clean, dry, oil and dust free gas.

Hoses

The connection hose must satisfy the following conditions:

- Use only pressure-resistant and intact hoses.
- The hose must have an appropriate diameter; an adapter may be used, if necessary.
- Secure hoses using appropriate hose clamps.


4.3.4 Operating the CO₂ Control



The CO₂ control is operated using "CO₂" parameter (CO₂). To prevent large amounts of CO₂ from escaping, CO₂ control is deactivated automatically while the door is open.

For information on how to set and activate the parameter, see → Chapter 7.3 'Setting, Activating and Deactivating Parameters' on page 75.

4.4 Removable Shelf




A shelf (approx. 503 mm x 426 mm) for static incubation is available as an option. This allows static incubation in climatic conditions almost identical to the cultures on the shaking table.

! NOTICE

The inserted shelf can change the climate conditions in the incubation chamber and lead to higher tolerances as it hinders air circulation. To prevent damage to cultures, the climate above and beneath the removable shelf should be checked frequently and, if necessary, monitored using mobile sensors.

The removable shelf can be inserted at two different heights and is very easy to remove.



Options

Depending on the position of the removable shelf, the following shake flasks can be placed on the tray underneath it:

- If the removable shelf is in the lower position, shake flasks with a volume of up to 1 litre (maximum height: 220 mm) can be placed on the tray.
- If the removable shelf is in the upper position, shake flasks with a volume of up to 3 litres (maximum height: 320 mm) can be placed on the tray.

4.5 Darkening

The glass pane of the door can be covered with white adhesive foil on the inside. This is used to darken the incubation chamber.

4.6 Analogue Output

4.6.1 Setup and Function



The device can optionally be equipped with an analogue output module. This provides 8 channels via which actual values and setpoints can be transferred to an external device.

The analogue output module is located on the rear and is in its own housing. The signal range corresponds to 4 mA to 20 mA with a precision of ± 0.05 mA.


The provider must pre-assemble and connect the cable. To connect the cable, the top plate of the housing can be removed by loosening the four hexalobular screws (M4x6). The cable is guided out of the housing using a cable gland. This protects the cable as well as the outlet module from mechanical influences and humidity.

4.6.2 Connection Assignment

The connections of the analogue output module are assigned as follows:

Channel	Connection	Function	Signal range
1	lout0 / AGND0	Temperature actual value	0 °C to 100 °C = 4 mA to 20 mA
2	lout1 / AGND1	Temperature setpoint	
3	lout2 / AGND2	Rotation speed actual value	0 min ⁻¹ to 500 min ⁻¹ = 4 mA to 20 mA
4	lout3 / AGND3/4	Rotation speed setpoint	
5	lout4 / AGND3/4	CO ₂ actual value	0 % to 20 % = 4 mA to 20 mA

Channel	Connection	Function	Signal range
6	Iout5 / AGND5	CO ₂ setpoint	
7	Iout6 / AGND6/7	Humidity actual value	0 % to 100 % = 4 mA to 20 mA
8	Iout7 / AGND6/7	Humidity setpoint	




4.7 Cable Pass-through

4.7.1 Setup and Function

A pass-through for cables and hoses can be installed on the left side of the housing. This can be used to guide additional sensors or gassing into the incubation chamber.

The pass-through reduces loss of heat and/or humidity and, if applicable, gas consumption if cables or hoses have to be passed into the incubation chamber.

The pass-through consists of a stable, black frame (1) into which blue sealing elements (2) are inserted. By removing layers, these elements can be adapted to the diameter of the cable or hose. The entire part is affixed to the casing by means of four knurled screws (3).



Options

4.7.2 Using the Cable Pass-through

WARNING




If an external device that is supplied with mains voltage is operated on the shaking table whilst it is operating, there is a risk that the cable might break or get jammed. This poses a risk of death by electrocution.

- Any mains voltage operated devices may only be used when the shake function is switched off (e.g. in conjunction with the "Temperature" parameter.)
- Any mains voltage operated devices may only be used in conjunction with the "Humidity" parameter if the device is adequately protected against humidity. Observe the permissible environmental conditions for operating the device.


NOTICE

To avoid damages when installing the cables and/or hoses in the incubation chamber, make sure that they do not rub and do not get jammed.

To correct insert cables and hoses into the incubation chamber, proceed as follows:

1.  Loosen the knurled screws on the cable pass-through frame.
2.  Remove the cable pass-through.
3.  Push the blue interior part out of the frame.






4. Split the blue modules in the middle and take out as many layers of segments as needed to make the opening slightly smaller than the diameter of the cable or hose.




Keep the removed parts of the segments in the bag provided. They are needed to reseal the hose pass-throughs once they are no longer needed.



5. Place the module halves around the cables and/or hoses.
The module halves must fit together in such a way that a 0.1 to 1.0 mm gap remains between the modules once they are put together. This ensures that the pass-through provides seals sufficiently once installed.



6. Pass the hoses and/or cables through the opening of the frame.
7. Generously lubricate the inner edge of the frame with the provided gel lubricant (Roxtec).



8. Push the complete modules placed around the cables and the complete modules back into the frame. Ensure that all module parts are on the same level.
9. Pass the cables and/or hoses through the opening of the casing.
10. Affix the frame to the cases using the knurled screws.

To seal an opening that is temporarily not required, a red plug is provided for a standard diameter (8 mm).

Accessories

5 Accessories

The following chapters describe all accessories that are generally available for the device. For special applications, please contact our customer service for advice.

5.1 Trays

Different trays are available for the device; these can be purchased individually or ordered with the device.

In addition to the universal table tray, which can be equipped as desired, various trays with fixed features are available for different purposes. Pre-fitted trays are equipped with one clamp type each. They are used if only a single size of flask is to be used for certain tasks. In contrast to the universal table tray, their holders cannot be changed. Pre-fitted trays feature a capacity that is up to 20% higher than an individually equipped universal table tray. Since no drill holes have to be taken into account in the grid, the clamps can be installed closer together.

The following trays are available:






Figure	Designation
	Universal table tray
	Tray with steel clamps
	Tray with pin holders for microtitre and deep-well plates

Figure	Designation
	<p>Tray with clamping assembly for microtitre and deep-well plates</p>
	<p>Tray with sliding bars</p>
	<p>Tray with Sticky Stuff</p>

5.1.1 Universal Table Tray

Overview



The tray referred to as “universal table tray” features drill holes on a grid so that it can be equipped as desired. For equipping, various clamps and test tube holders are available; these can be combined as desired (➔ Chapter 5.2 ‘Clamps and Other Holders’ on page 58).

The universal table tray is made of anodised aluminium and can be sterilised in the autoclave if required.


The separately available Sticky Stuff adhesive matting can also be stuck onto the universal table tray.

Accessories

Technical Data

Data	Value
Material	Aluminium
Size	480 x 420 mm
Weight	2.5 kg
Threaded holes	M4
Threaded holes	224
Threaded hole grid	28.28 x 28.28 mm
Sterilisation in an autoclave	YES

5.1.2 Tray with Steel Clamps




Fitting identical clamps on the entire tray results in the following capacities:

Flask size [mL]	Number of flasks per N tray
25	105
50	69
100	46
250	25
500	15
1000	10
2000	6
3000	5

5.1.3 Tray with Pin Holders

Overview




For applications in which large numbers of microtitre or deep-well plates need to be incubated, various trays with pin holders are available. These enable loading with several layers of microtitre and deep-well plates.


The plates can be stacked. This allows you to simultaneously incubate up to 24 deep-well plates and up to 36 microtitre plates on one N tray.

The trays are designed for plates with the dimensions 85.1 x 127 mm.

To ensure the cultures receive the optimum oxygen supply, spacers can be placed between stacked plates. It is available in two variants:



Ring spacers (10 mm high) are placed on the pins individually. Depending on the type of tray loading, this makes it possible to remove individual plates or stacks of plates.



Quickload spacers are long plastic strips (4 mm high) that span across several plates, thus allowing you to save time while loading.

! NOTICE

The spacers are made of plastic and therefore cannot be autoclaved.

Accessories

Technical Data

Data	Value
Material	Aluminium
Fastening screws	M5 x 12
Cleaning	Mild neutral cleaning agent
Disinfection	Commercially available disinfectant
Sterilisation in an autoclave	YES
External dimensions of the microtitre plates	85.1 x 127 mm
Height of the deep-well plates	42 mm



5.1.4 Tray with Clamping Assembly

Overview




To affix microtitre and deep-well plates, there is a quick clamping assembly. Two versions of this clamping assembly are available:


Tray with flat clamping assembly (horizontal incubation): The flat clamping assembly is a profile made of sheet metal that is equipped with an angled strip (2). On the other side, there is an edge featuring a foam rubber strip (3). There are two spacers on the edge (1) for positioning microtitre plates or deep-well plates.



Tray with clamping assemblies tilted at an angle of 20° (angled incubation): The folded clamping assembly is wedge-shaped metal sheet with two profiles. The lower profile is an angled bar (3). The upper profile is a U profile into which the cellular rubber string (2) is inserted. There are two spacers on the upper edge (1) for positioning the microtitre plates or deep-well plates.



The trays with clamping assemblies are designed for microtitre and deep-well plates with dimensions 85.1 mm x 127 mm. To ensure sufficient clamping force can be achieved, plates with a web height of at least 3 mm must be used.




Technical Data

Data	Value
Rail material	Aluminium
Foam rubber material	CR rubber
Temperature range	≤ 80°C
Cleaning	Mild neutral cleaning agent
Disinfection	Commercially available disinfectant
Sterilisation in an autoclave	NO
Size of microtitre plates/deep-well plates	85.1 x 127 mm

Accessories

5.1.5 Tray with Sliding Bars

Overview



Trays with sliding bars enable the affixing of vessels of various shapes and sizes. The sliding bars can be affixed to any point on the support bars. This also allows you to affix bottles with vertical walls and a curved base.

The bars enveloped in soft material are arranged on two different levels to securely hold bottles of different sizes.

The scope of delivery for the tray includes the fixed mounted frame and 5 movable sliding bars.

Technical Data

Data	Value
Material	Aluminium, plastic
Cellular rubber mat	EPDM cellular rubber
Cellular rubber cover	Armaflex
Cleaning	Mild neutral cleaning agent
Disinfection	Commercially available disinfectant
At operating temperature	65 °C
Sterilisation in an autoclave	NO


5.1.6 Tray with Sticky Stuff

! NOTICE

If condensate forms on the tray or the culture vessels, the adhesiveness of the Sticky Stuff adhesive matting is no longer guaranteed. This can result in cultivation vessels separating from the adhesive matting and breaking.

Hence, consider the following when using Sticky Stuff:


- Ensure that condensate does not form on the tray or the culture vessels. This is particularly necessary when cultivation is started at low temperatures and the temperature is then increased.
- Let cultivation vessels that were stored in the fridge warm up to ambient temperature first before placing them on the adhesive matting.



- If you are looking for a very flexible option for equipping the tray, the tray with Sticky Stuff offers an ideal alternative.
- However, you have to keep in mind that rotation speeds are limited when using Sticky Stuff (for more information on this, refer to the table at the end of the chapter).


i Due to limited resistance to disinfectants as well as the risk of unintentional detaching of flasks, Sticky Stuff is not suitable for cultivating pathogenic microorganisms.

Using Sticky Stuff




- Use only vessels with a broad flat base. Large Erlenmeyer flasks (e.g. 3000 mL) adhere more strongly than smaller ones (e. g. 500 mL).
- Ensure that the entire bases of the flasks are on the adhesive matting. They must not extend beyond the edge of the tray.
- Check vessels for damage prior to use and replace, if necessary. Never use damaged vessels!
- Prior to putting down any vessel, ensure that its base is dry, clean and grease-free.

Accessories



- Prior to the shaking process, gently pull on every vessel to ensure they are all stuck on firmly.
- If the humidity is too high or the temperatures are too low or if there are extreme jumps in temperature (e.g. when using the timer function), keep an eye on condensate. Condensate can result in vessels detaching from the adhesive matting.
- To remove vessels, gently and evenly pull or push on the neck and wait a few seconds.
Never apply force!
- In case of large vessels, it can take 20 to 30 seconds until they detach from the adhesive matting.
- Vessels that are stuck can be removed from the adhesive matting by using a syringe to inject water under the flask.
- Due to their shape (wide base, short neck), Fernbach flasks in particular can be difficult to remove. If necessary, cover part of the adhesive matting with the protective foil provided.
- The adhesive power can deteriorate over time due to dust and dirt. To clean and restore full adhesive power, thoroughly wipe down the surfaces with a brush or a dish sponge and clear water with mild detergent (dishwashing liquid). Then allow to dry overnight.
- Quaternary ammonium compounds are suitable for disinfection.
- Note the application time and rinse thoroughly with water afterwards. If the adhesive matting is disinfected at regular intervals, it might need to be replaced sooner.

Replacing the Adhesive Matting



To replace the adhesive matting proceed as follows:

1. Thoroughly moisten the tray with water.
2. Release the adhesive matting on one side of the tray and then pull upwards at an angle.
3. Degrease the tray with acetone and apply new wet adhesive matting (as per separate installation instructions). Only remove protective foil prior to use.
 - The removed adhesive matting can be reused and can be reapplied after regeneration in water.

Service Life

Sticky Stuff is a consumable that typically has to be replaced every 2 to 5 years. The service life depends on how the material is used and cleaned. If you are regularly using aggressive chemicals to clean or disinfect, we recommend replacing the Sticky Stuff every 2 years.

! NOTICE

Normal ageing and/or use of aggressive chemicals reduces the adhesiveness. This can result in vessels coming loose and thus damaging the device.

- Replace severely worn adhesive matting.
- Only use absolutely clean, dry and grease-free adhesive matting.
- Check the adhesiveness prior to use. If you are unsure, slowly increase the rotation speed and check that the vessels adhere safely.

Suitable/Unsuitable Vessels

Sticky Stuff is suitable for use in combination with the following vessels:

- Erlenmeyer or Fernbach flasks made from glass or polycarbonate with a smooth bottom and without crowning

When using unsuitable vessels, the adhesive power is reduced significantly. If unsuitable vessels are used in combination with Sticky Stuff, it is the user's responsibility to check if the adhesiveness suffices. In addition, only reduced rotation speeds are possible when using unsuitable vessels. Unsuitable vessels include, for example:

- High and narrow vessels
- Bottles
- Erlenmeyer flasks with crowning and correspondingly reduced contact area

Accessories

Maximum Rotation Speeds with Sticky Stuff

To ensure that the flasks do not detach from the adhesive matting, the maximum permissible rotation speed is limited when using adhesive matting.



The following guidelines only apply to undamaged, completely dry adhesive matting and flasks free of grease. If old or dirty adhesive matting is used, there is a risk that flasks detach even at lower rotation speeds.

Schott Duran® glass Erlenmeyer flask	Filling	Maximum permissible rotation speed	
		25 mm throw	50 mm throw
25 to 750 mL	20 %	250 min ⁻¹	200 min ⁻¹
1000 mL	20 %	300 min ⁻¹	250 min ⁻¹
2000 mL	20 %	300 min ⁻¹	250 min ⁻¹
3000 mL	20 %	350 min ⁻¹	300 min ⁻¹
5000 mL	20 %	300 min ⁻¹	250 min ⁻¹

Corning plastic Erlenmeyer flask	Filling	Maximum permissible rotation speed	
		25 mm throw	50 mm throw
125 to 3000 mL	20 %	300 min ⁻¹	200 min ⁻¹

Corning plastic Fernbach flask	Filling	Maximum permissible rotation speed	
		25 mm throw	50 mm throw
3000 mL	20 %	300 min ⁻¹	250 min ⁻¹

5.2 Clamps and Other Holders

For individual fitting of the universal table tray, various clamps and holders are available.

5.2.1 Clamps

For fitting a universal table tray, clamps of various sizes are available. These can be ordered individually and mounted on the universal table tray.

Stainless Steel Clamps




The following stainless steel clamps are available:

For flask type	Volume		
Erlenmeyer	25 mL	500 mL	4000 mL
	50 mL	1000 mL	5000 mL
	100 mL	2000 mL	
	250 mL	3000 mL	
Fernbach	1800 mL	2800 mL	

Data	Value
Material	Stainless steel
Fastening screws	25 to 50 mL: M4 x 6 100 to 5000 mL: M4 x 8
Temperature range	95 °C
Cleaning	Mild neutral cleaning agent
Disinfection	Commercially available disinfectant
Sterilisation in an autoclave	YES

Plastic Clamps



The following plastic clamps are available:

For flask type	Volume		
Erlenmeyer	100 mL	250 mL	500 mL

Data	Value
Material	POM Co polymer
Fastening screws	M4 x 6
Temperature range	65 °C
Cleaning	Mild neutral cleaning agent
Disinfection	Commercially available disinfectant
Sterilisation in an autoclave	NO

Accessories


5.2.2 Test Tube Holder



Test tube holders are used to securely affix different sized test tubes. Test tube holders can be screwed onto a universal table tray or placed on Sticky Stuff adhesive matting.

The following test tube holders are available (details and special variants on request):

- For long test tubes; Ø 8 to 30 mm
- For short test tubes; Ø 12 to 18 mm
- For plastic tubes with ventilation lid; Ø 16 and 30 mm
- Special holders, e. g. for 600 mL culture vessel



If necessary, the inserts with the tubes can be tilted by loosening the black nuts (1). The tilt can be set freely. Then tighten the nuts again.

The entire inner part with the holders for the tubes can be removed by loosening the black nuts, whereby the u-shaped holder remains on the tray.

When inserting the inner parts, ensure that the feet of the holder (part on the tray) on both sides rest between the rubber ring (3) and the Teflon washer (2).

Test tube holders can also be used on a tray with Sticky Stuff. To do this, the pre-installed screw must be removed from the base plate.

! NOTICE

The test tube holders adhere extremely strongly to the Sticky Stuff so that water has to be sprayed underneath the edge of the holder with a syringe in order to remove them. This is done to prevent damage to the holder or the tray.

5.3 Box for Microtitre Plates

Overview




The box for microtitre plates is used for low-vapour cultivation of microtitre plates and deep-well plates. It protects cultures from drafts in the incubation chamber and also offers a stable container in which cultures can be transported.

The box for microtitre plates consists of an aluminium container with a removable lid into which a replaceable paper filter is integrated. A microtitre insert with screw-mounted pins is used for mounting microtitre plates and deep-well plates.


For shaking, the box for microtitre plates can be screwed onto a universal table tray or placed on the Sticky Stuff adhesive matting.

Setup



- 1 Filter
- 2 Filter washer
- 3 Top plate
- 4 Microtitre insert
- 5 Quickload spacers
- 6 Container

Installation




The box for microtitre plates is affixed to the tray with four Philips head screws. When delivered, the fastening screws are covered with plastic cap nuts. These must be removed prior to installation.

Alternatively, the box for microtitre plates can be placed on the Sticky Stuff adhesive matting. In this case, all fastening screws must be removed to avoid damaging the adhesive matting.

During installation, ensure that the tray is always loaded evenly.


Loading



To improve transfer of oxygen to the cultures and facilitate the removal of the plates, spacers (Quickload Spacers) (1) can be placed between the individual layers. Prior to loading, the Quickload Spacers must be removed. Following that, microtitre or deep-well plates can be inserted.

For cultivations with a low oxygen requirements, Quickload Spacers do not have to be used.

Inserting/Replacing a Filter



To insert or replace a sterile filter (3) the filter washer (2) must be removed first. To do so, press the locking button (1) on the filter washer and lift up the filter washer. Following that, the filter can be inserted and the filter washer can be put back in its place.

Accessories

Sterilising

The box for microtitre plates can be autoclaved (recommendation: 20 min at 120 °C). To do so, remove the Quickload Spacers first and disinfect them using commercial disinfectant.

Limiting the Rotation Speed

When there are high rotation speeds or insufficient grip due to humidity or dirt, the box for microtitre plates can separate from the Sticky Stuff and cause damage to the incubation chamber. The maximum permissible rotation speed is therefore limited as follows:

Tray	25 mm throw	50 mm throw
On universal table tray	350 min ⁻¹	250 min ⁻¹
On Sticky Stuff	150 min ⁻¹	150 min ⁻¹

Technical Data for Container with Top Plate and Tray

Data	Value
Dimensions	465 x 280 mm
Weight	4.23 kg
Filter, paper, round, Ø	185 mm
Screws for microtitre tray	M4 x 8 hexalobular
Screws for microtitre box	M4 x 12 Phillips head
Material	Aluminium, autoclavable
Detergent	Mild dishwashing liquid or neutral cleaning agent

Technical Data of the Quickload Spacer

Data	Value
Dimensions	412 x 14 x 5 mm
Quantity	12 units
Material	Polyamide 6.6 can be sterilised
Detergent	Mild dishwashing liquid or neutral cleaning agent

Loading Capacity

Data	Value
Microtitre plates	18 units
Deep-well plates, height 42 mm	12 units



Valid for standard plate size 85.1 x 127 mm.

5.4 Profibus DP and Modbus TCP Gateways

The Profibus DP gateway and the Modbus TCP gateway are used to connect the incubator shaker to a PLC. The gateways translate the communication protocol of the incubator shaker into Profibus DP / Modbus TCP and thus enable data to be exchanged between the incubator shaker and a SCADA system.

The gateways can be used for the following purposes:


- Record and archive the parameter data of the incubator shaker on a SCADA system (reading setpoints and parameter values as well as door status and PIN function)
- Control the incubator shaker via a SCADA system (sending new parameter setpoints)

The incubator shaker and the gateways can either be connected directly (only Profibus DP Gateway) or integrated through a common network. For stacked devices, one gateway is required per device unit.


For further information on the gateways, refer to the Device Descriptions.

Accessories

Profibus DP Gateway



Modbus TCP Gateway



5.5 eve®



eve® is a platform software for planning, execution and analysis of bioprocesses. eve® makes it possible, for example, to record bioprocess data and store it in a central database. The software offers workflows from simple bioprocesses to the planning and execution of complex strategies with various process phases.

eve® makes it possible to generate and store bioprocess knowledge. For example, various libraries for storing information on organisms and culture media are available. Thanks to soft-sensors, additional knowledge can be generated.

In addition to INFORS HT products, biotech machines and analysis devices from third-part manufacturers can be connected. This makes it possible to holistically control, monitor and analyse bioprocesses using a software.

eve® is installed on a centralised server. Access takes place via a browser, no client side installation is required. Bioprocess data is therefore available directly via the browser and independent of the operating system.

Various packages of the software are available. This makes it possible to adapt it to the individual needs and requirements of its users. eve® (the premium version) is also suitable for working in a validated environment as per FDA CFR 21 Part 11.

Installation and Commissioning

6 Installation and Commissioning

Only the manufacturer’s qualified expert personnel or persons authorised by the manufacturer may install and initially commission the device. Hence, the following section only lists the requirements for the installation location to be observed by the provider.

WARNING

Installation and initial commissioning require trained expert personnel with sufficient experience. Errors during installation may lead to dangerous situations or significant damage to property.

- Only the manufacturer’s expert personnel or persons authorised by the manufacturer may install and initially commission the device.
- Contact the manufacturer if the device is to be placed in a different location.

6.1 Operating Conditions at the Installation Location

Operating Conditions

To achieve optimal and reproducible results, the device should be set up in stable ambient conditions without significant temperature and humidity fluctuations. Changes in ambient temperature and humidity (even short-term) can have a negative impact on the climate in the incubation chamber.

Temperature range	10 to 32 °C
Humidity	10 to 85 %
Restrictions	<ul style="list-style-type: none"> ■ Do not expose to direct sunlight ■ Do not expose to dust ■ Do not expose to vibrations

The device may only be set up indoors.

Installation and Commissioning

Unsuitable Installation Sites

In order to achieve the desired climate in the incubation chamber and to be able to control it as precisely as possible, the following installation locations must be avoided at all costs:

- Poorly ventilated recesses or areas in the exhaust heat air stream of air conditioners or other sources of heat
- Directly underneath, next to or in the air stream of the air conditioners or other devices that generate strong air flows (e.g. circulation fans in clean rooms)
- Directly next to device with strong heat radiation, such as heaters or autoclaves, or in their exhaust heat stream
- Directly next to refrigeration devices, such as deep freezers or refrigerated centrifuges, or in their exhaust heat air stream



To be able to achieve the desired temperature in the incubation chamber, the ambient temperature directly at the device is decisive. This can be considerably higher than the temperature at other positions in the room due to the waste heat of the unit or due to other devices with strong heat radiation in the immediate vicinity!

6.2 Requirements for the Mains Connection

To avoid dangers due to electrical current, the in-house mains connection must meet the following requirements:

- Constant power supply
- Recommendation: In the building, secure the power supply using a fault current protection switch (RCD – Residual Current Device).

In addition to that, ensure the following:

- The voltage values of the device match those of the local mains voltage. Note the information on the identification plate.
- Use the power cable provided. If the power cable becomes defective, replace it with a power cable of the same type.
- The mains connection can be accessed at all times.


Refer to the technical data for the electric connection values.

6.3 Minimum Distances to the Device


When setting up the device, the following minimum distances must be observed to ensure adequate ventilation and access to the most important connections:

Installation and Commissioning

Minimum Distances Side




Minimum Distances Back (with and without Humidity Control)



Installation and Commissioning


Placing the Device on a Table



When placing the device on a table, observe the following:

- To prevent the table from vibrating, use a heavy table with diagonal braces as the minimum (ideally use a stable laboratory bench). Alternatively, the table can be affixed to the wall.
- The minimum required depth of the table is 650 mm.
- You must leave a ventilation gap of at least 100 mm between the device and rear wall.
- If shelves or cupboards are installed above the table, you must leave a minimum distance of 100 mm.
- No gas outlets, shelves or cupboards must be in the way.

Placing the Device under a Table



When placing the device under a table, observe the following:

- You must leave a ventilation gap of at least 100 mm between the device and rear wall of the table to ensure heat produced by the device can escape.
- The minimum distance between the device and the underside of the table top is 100 mm.
- When operating devices with installed cooling, heat can accumulate under a closed laboratory bench. This can result in the desired temperature not being achieved in the incubation chamber. Furthermore, heat accumulation increases energy consumption because more cooling is required. Hence, we recommend only installing the device under a laboratory bench with an ventilation opening.

! NOTICE

Failure to comply with the required minimum distances can result in components of the device overheating and the device being damaged. As such, please observe the following points:

- Never cover the air vents on the right-hand side or those on the rear of the device.
- Never position the device right up against a wall.


Operation

7 Operation

7.1 Switching the Device on

! NOTICE

The shaker drive can start up automatically, if the device was not switched off correctly beforehand. Loose items in the incubation chamber can damage the device and cultivation vessels if this happens.



- ➔ Activate the power switch on the right side of the housing.
 - Once switched on, the power switch will light up in green and the device will automatically run a self-test. As soon as the initialisation process is complete, the device is ready for operation.

7.2 Loading the Device

7.2.1 Opening the Door

The door can be opened while the device is running. The shaker drive, temperature control and all other parameters are stopped automatically.

To open the door, proceed as follows:

1. ➔ Temporarily stop the device by slightly opening the door.
2. ➔ Wait until the table stands still.
3. ➔ Open the device door all the way.

The shaker drive and all other parameters will start up again automatically as soon as the door is closed.



If you wish to stop the shaker drive slowly, e.g. to avoid culture liquid from spilling out, you have to set the "Rotation speed" parameter to *OFF* prior to opening the door. In this case, the shaker drive stops slowly, with the brake force set in the Settings menu (➔ 'Set Brake Power' on page 89).


7.2.2 Inserting and Removing the Tray

Removing the Tray

To remove the tray, proceed as follows:

1. ➤ Open the device door all the way.
2. ➤ Unscrew and remove the knurled screw fixing the tray.
3. ➤ Use the grip to lift the tray and take it out of the incubation chamber by pulling it forward along the side guides.

Inserting the Tray



To insert the tray, proceed as follows:

1. ➤ Open the device door all the way.
2. ➤ Insert the tray between the two side guides on the table (2).
3. ➤ Use the grip to slide the tray on the table all the way back until it reaches the stop (1).
4. ➤ Ensure that the tray is snapped into the two conical plugs on the table (3).
5. ➤ Affix the tray using the knurled screw; tighten the screw so that it cannot come loose.

! NOTICE

If the tray is not held in place securely on the table, the tray's movement may damage the interior of the device.

- Do not start up the device unless the tray has been inserted correctly and affixed securely.



If you are unable to insert the tray correctly, perform the following checks:

- Remove the tray and check it is not twisted or bent.
- Check the incubation chamber for foreign objects and remove these.
- If it is still not possible to insert the tray correctly, contact your nearest INFORS HT representative.

Operation

7.2.3 Mounting the Holders

! NOTICE

The threaded holes of the tray can be damaged if the fastening screws are not screwed straight into the thread.

- Place the screws vertically on the drill holes.
- Ensure they can be tightened easily.

! NOTICE







All holders are supplied with pre-fitted screws. If a test tube holder or box for microtitre plates is placed on the Sticky Stuff adhesive matting, there is a risk that the adhesive matting is damaged by protruding screws.


Remove the screws before you place test tube holders or microtitre plates on the Sticky Stuff adhesive matting.

Mounting a Holder

Clamps, test tube holders and boxes for microtitre plates are fixed to the tray using screws. The device is delivered with pre-fitted screws. The screws are each secured with one flat gasket at the bottom so that they cannot fall out. Only use the screws provided or screws of the same size for mounting.

To mount a holder, proceed as follows:

1.  Loosen the flat gaskets (1).
2.  Position the holder on the tray.
3.  Centre a screw (2) on the threaded hole in the tray and screw it in loosely. It must still be possible to turn the holder.
4.  Align the holder so that all screws are vertical above the respective threaded hole in the tray.
5.  Insert the screws loosely. Ensure that the screws are screwed in straight and do not tilt.
6.  Evenly tighten all screws cross-wise.



Screw Sizes

! NOTICE

If screws that are too long are used to install the holders, these will stick out at the bottom of the tray. This has the effect that the tray can no longer be inserted and affixed correctly.


If you have to replace lost fastening screws, you must use screws that comply with the specification below.

Holder	Size	Screw	Flat gasket
Steel clamps	25 to 50 mL	Flat head screw with Phillips head M4 x 6 A4	D = 3.2 x 12 x 0.5
	100 to 5000 mL	Flat head screw with Phillips head M4 x 8 A4	D = 3.2 x 12 x 0.5
Plastic clamps	100 to 500 mL	Flat head screw with Phillips head M4 x 6 A4	D = 3.2 x 12 x 0.5
Test tube holder	Ø 8 to 30 mm	Oval head screw with Phillips head M4 x 6 A2	D = 3.2 x 12 x 0.5
Boxes for microtitre plates	n. a.	Oval head screw with Phillips head M4 x 12 A2	D = 3.2 x 12 x 0.5


Operation

7.2.4 Tips & Tricks for Loading the Tray



Observe the following notices when loading the tray:




- The working volume should not exceed 1/3 of the total volume of the vessel.



- To ensure smooth operation, place the cultivation flasks symmetrically in the middle of the tray. Do not place heavy vessels at the edge of the tray.



- If the flasks extend beyond the edge of the tray, they may be damaged or broken if they collide with the wall of the device. Therefore, always position cultivation vessels on the tray so that they do not protrude.



- If the tray is only loaded lightly and is going to be run at high rotation speeds, place additional cultivation vessels filled with water on the tray. This will make the device run smoothly.

At shaker speeds of approx. 200 min⁻¹ to 250 min⁻¹ (depending on the throw and the position of stacked device units), the load distribution plays only a minor role.

CAUTION


If the loading mass of the table is too high or too low or the load is distributed unevenly, high rotation speeds can cause vibrations. This can result in the device moving uncontrollably.

- Never operate the device without a tray and loading.
- In case of strong vibrations, reduce the rotation speed and check the loading weights or the distribution of the load.

7.3 Setting, Activating and Deactivating Parameters

Setting the Setpoint and Switching on the Parameter

To set the setpoint for a parameter and switch on the parameter, proceed as follows:



1. Use the **Scroll** key (1) to select the desired parameter pair.
 - ➔ The view box shows the actual values of the selected parameters.
2. To activate programming, press the upper or lower **SET** key (2), depending on which parameter is to be set.
 - ➔ The view box shows the last setpoint value of the parameter. The *SETPOINT* lettering indicates that the parameter can be adjusted.

i If no input is made 10 seconds after pressing the **SET** key, the **SET** key must be pressed again.

3. Use the **Plus** or **Minus** key (3) to set the setpoint you want to use for the selected parameter.
 - ➔ The entered value is saved automatically. A separate confirmation is not necessary. If the parameter is not activated thereafter, the change is discarded.
4. To activate the parameter, press the **ON/OFF** key (4) on the corresponding control panel.
 - ➔ The parameter is activated immediately.
 - ➔ *SETPOINT* goes out. The *ON* message briefly appears in the view box. Following that, the actual value of the parameter is displayed.



Operation



When starting up the shaker drive, use the time until the setpoint is reached to check whether the cultivation flasks are secured on the tray.



The parameters need a little time to reach their set setpoints. Until they have done so, the messages *HIGH* or *LOW* is displayed, depending on whether the actual value is higher or lower than the setpoint.

Deactivating the Parameters



The parameters are deactivated using the same procedure as for activation. Select the parameter you wish to deactivate using the **Scroll** key, and then press the **ON/OFF** key to deactivate it. When a parameter is deactivated, the view box shows the message *OFF*.



If a parameter is switched off, the parameter is no longer controlled, but continues to be measured. The measured value (actual value) is displayed in greyed out text.

7.4 Timer Function

7.4.1 Overview

! NOTICE

If cultivation is started at low temperatures and the temperature is then increased (e.g. when using the timer), condensation can form on the flasks because these are heated up slower than the ambient air. When using the device in conjunction with the Sticky Stuff adhesive matting, this can lead to the flasks coming off the adhesive matting.

The timer function can be used to set defined sequences. For example, the parameter setpoints can be changed after a certain time or the starting of the cultivation can be delayed. The timer can be programmed in two different modes:

- One-time change from phase 1 to 2
- Cyclical changing between phases 1 and 2



More complex sequences or processes can be programmed using the eve® bioprocess platform software.




If the device is controlled remotely via the Ethernet interface (e.g via eve®), the timer function is blocked. Running timers are interrupted.

One-Time Change from Phase 1 to 2

If the device is programmed this way, the setpoint settings for the cultivation process parameters will change when the specified time expires. The device will then keep running using the setpoints specified for the second phase until the device is stopped by deactivating the parameters.

Example applications:

- Starting the cultivation process on a time delay
- Induction of a protein expression
- Stopping or slowing down a cultivation process after a defined period of time



Operation




To program a one-time change from phase 1 to phase 2, the timer must be deactivated for the second phase (*Time 2= OFF*). If the timer is activated for the second phase (*Time 2= ON*), the device switches cyclically between phases (see next example).

Cyclical Changing Between Phases 1 and 2

If the device is programmed this way, two different parameter settings will be repeated on an endless, precisely timed cycle. The two intervals (phase 1 and phase 2) alternate until the cultivation process is stopped manually by deactivating the parameters.

Example application:

- Simulation of day and night




7.4.2 Programming Timer

To programme the timer, proceed as follows:

1. Press the **TIMER** key to select the timer function.
 - ➡ The Timer overview is opened.
2. Press the **TIMER** key again to programme phase 1 of the timer.
3. Switch on phase 1 and set the time. To do so, press the upper **ON/OFF** key and then use the upper **Plus** or **Minus** key to set the desired runtime of phase 1.





4. ➔ Set the parameters for phase 1:
 - Use the **Select** key to select the desired parameter.
 - Activate the parameter with the lower **ON/OFF** key.
 - Use the lower **Plus** or **Minus** key to set the setpoint.
 - Repeat the process for all desired parameters.
5. ➔ Once all parameters have been set, press the **TIMER** key to switch to phase 2.
6. ➔ Depending on whether a simple change from phase 1 to phase 2 or a cyclic change between both phases is to be programmed, the procedure differs as follows:
 - Simple change: Ensure that the second timer is switched off. If necessary, switch off timer 2 with the upper **ON/OFF** key.
 - Cyclic change: Use the upper **ON/OFF** key to switch on the timer for phase 2 and then use the upper **Plus** or **Minus** key to set the desired runtime of phase 2.
7. ➔ Set the parameters for phase 2 analogous to those for phase 1.



If the cultivation process is to be stopped after a defined time, all parameters can be switched off in the second phase. This causes the parameters to be switched off after the entered time for phase 1 has elapsed and the cultivation process is thus stopped.

8. ➔ Once all parameters have been set up, press the **TIMER** key. The timer overview appears again with information on the parameters of the two phases.


Next steps:

- By pressing the **TIMER** key, the settings of the two phases can be viewed again and adjusted if necessary.
- By pressing the upper or the lower **ON/OFF** key, the timer can be started (➔ Chapter 7.4.3 'Starting the Timer' on page 80).
- You can reset the timer settings by means of a long press (5 s) of the upper or lower **ON/OFF** key.
- To leave the Timer menu, press the **Select** key. All settings are saved.

Operation


7.4.3 Starting the Timer

To start a programmed timer, proceed as follows:



- ➔ In the Timer overview, press either the upper or the lower **ON/OFF** key.
- ➔ As soon as the timer function has been activated, the two phases incl. their runtimes are displayed on the lower edge of the display.

Simple Change



The cultivation process now runs with the parameters of the first phase until the time entered in the first timer (*PHASE 1*) has elapsed.

At the end of the entered time, the setpoints for phase 2 are activated. They remain active until the setpoints are changed manually.

The end of the timer is indicated by the *END* message in the status bar. In addition, an acoustic alarm sounds every 60 seconds. The message and the acoustic alarm can be cancelled by switching off the timer. To do this, open the timer menu using the **TIMER** key and then switch off the timer with the upper or lower **ON/OFF** key.

Cyclic Change








Once the timer has been started, the cultivation process runs alternately with the setpoints for the first and second phases until the timer is manually switched off. The active phase is shown in blue.

7.4.4 Viewing and Changing Timer Settings

The settings (duration of the phases as well as parameter setpoints) of a running timer can be viewed and adjusted if necessary. Depending on whether the setpoints or the duration of the phases are changed, the timer behaves as follows:

- If the duration of the active phase is changed, the active phase is restarted.
- If only the setpoints or the duration of the non-active phase are changed, the timer continues to run without interruption.

To change the settings of a running timer, proceed as follows:

1.  Press the **TIMER** key to select the timer function.
 - ➔ The Timer overview is opened.
2.  Switch to the timer programming mode by pressing the **TIMER** key again.
3.  If necessary, reset the duration of the two phases and the setpoints of the parameters (➔ Chapter 7.4.2 'Programming Timer' on page 78).
4.  Use the **TIMER** key to confirm.
5.  If you want to accept the changes, confirm the message with **SET**. If you want to discard the change, confirm with **Select**.






When the timer is active, it is not possible to change the parameter setpoints in normal mode. To change the setpoints, you have to either adjust the settings of the timer or switch off the timer.

Operation

7.4.5 Stopping the Timer

The timer can be stopped at any time. To do so, proceed as follows:

1.  Press the **TIMER** key to select the timer function.
2.  Press the **ON/OFF** key on the upper or lower control panel to switch off the timer function.
 - If you only press the **ON/OFF** key briefly, the timer is switched off and the settings (time and setpoints) of the two phases are saved.
 - If you press the **ON/OFF** key for five seconds, the timer is switched off and the settings (time and setpoints) are reset.
 - ➡ The timer display at the bottom of the display disappears, phase 1 and phase 2 are set to *OFF*.
3.  Press the **Select** key to return to normal operating mode.



Opening the door or a power interruption do not deactivate the timer function.

Deactivating an Individual Timer

Alternatively, the two timers (*Time 1* and *Time 2*) can also be deactivated separately. Please note:

- If the first timer (*Time 1*) is deactivated, the second timer (*Time 2*) is also deactivated.
- If the second timer (*Time 2*) is deactivated, the first timer (*Time 1*) remains active.

7.5 Using eve[®] to Operate the Device

Overview



For detailed information on how to use eve[®] to operate the device, please read the documentation supplied with eve[®].

The Ethernet interface of the device allows the device to be operated via an external software (eve[®] or laboratory management/monitoring system from a third-party manufacturer, for details on the Ethernet interface, see → Chapter 3.2.3 'Ethernet Interface' on page 30). The following points must be observed if the device is operated via the Ethernet interface:

- The parameters cannot be activated and deactivated manually via eve[®]. If a permissible setpoint is sent to the device, the parameter is activated automatically. A parameter can be deactivated by sending the setpoint 0 to the device.
- For a parameter to be activated and deactivated via eve[®], it must be activated manually once on the device. If a parameter is deactivated on the device, this remains deactivated, even if eve[®] sends a setpoint.
- If the device is connected to eve[®], all setpoints set in eve[®] are applied automatically. Any setpoints manually set on the device are overwritten.
- If the device is connected to eve[®], the timer function of the device is blocked. Running timers are interrupted automatically.




Requirements

To ensure the device can be operated via the Ethernet interface, the function must be activated in the Settings menu. Here, you can choose between the *Read only* and *Read & write* options (→ 'Ethernet Connection' on page 87).

Operation

Displays on the Device

If the device is controlled using eve®, this is displayed on the device as follows:



- While the device is being registered in eve®, the working light of the device flashes. This is used, in particular, to identify the device when devices are stacked.
- Arrow symbols indicate the connection status:
 - No symbol visible: Not connected
 - Arrows greyed out: Connected and IP received from DHCP, but no communication
 - Arrow symbols light up in orange with each read and write access. If only one arrow lights up, the device is in *Read only* mode. If both arrows light up, the device is in *Read & write* mode.
- If setpoints are written to the device, *REMOTE* flashes next to the changed setpoint. If there is an alarm for a parameter marked *REMOTE*, the writing *REMOTE* alternates with the red alarm symbol (*HIGH/LOW*) in one-second intervals.
- If a parameter has been deactivated by sending setpoint 0, this is indicated with *REMOTE OFF*.

Displaying the IP Address of the Device

The IP address of the device is displayed in the Setting menu, in the *Ethernet connection* option (↔ 'Ethernet Connection' on page 87).


7.6 Settings Menu (Option Function)

7.6.1 Opening the Settings Menu

The Settings menu enables you to adjust the main device settings. To open the device's Settings menu, proceed as follows:

→ Press the **OPTION** key.

➔ The functions in the Settings menu are displayed as a list. The selected function is displayed in a large black font.



7.6.2 Using the Settings Menu

- You can use the upper **Plus** and **Minus** keys to select the desired setting, and the lower **Plus** and **Minus** keys to set a value.
- ON/OFF functions can be activated or deactivated with the lower **ON/OFF** key.
- There is no need to save changes, they are applied automatically.
- You can leave the Settings menu by pressing the **OPTION** key or the **Select** key. The Settings menu also closes automatically, if no key is pressed for 20 seconds.




The limits for the allowed setpoints of the parameters can only be set within the factory-set values. If the setpoint for a parameter is limited in the Settings menu of the device and a user attempts to enter a higher value, the *MIN* or *MAX* message appears.

Operation

7.6.3 Settings

Event List



The event list shows the last 18 events including their timestamps (date and time). The latest event is always at the top.

The following events are displayed in the event list:

- Activating/deactivating parameters (manually on the device, remotely or by the timer)
- Changing of setpoints
- Opening the door (incl. duration)
- Alarms and error messages (alarms and error messages are additionally marked with a red exclamation mark symbol)

The event list consists of a maximum of three pages with six entries each. Use the lower **Plus** or **Minus** key to scroll through the different pages of the event list.

The event list can only be displayed locally on the device and cannot be exported.



The event list does not correspond to an audit trail in the sense of FDA 21 CFR Part 11. The data stored in the event list can and may therefore not be used in the regulated environment.


To record and store the data under GMP conditions, you need eve® or comparable software with an audit trail function.

Info

Display of device and status information. The following information is displayed:

- *Mainboard Firmware*: Shows the version of the controller firmware that is currently installed.
- *Display Firmware*: Shows the version of the display firmware that is currently installed.
- *Operating hours shaker*: Shows the operating hours of the shaker.
- *Operating hours fans*: Shows the operating hours of the fans.
- *Number of door openings*: Shows how often the door of the device has been opened.
- *Number of pulses humidifier pump*: Shows how many switching cycles (pulses) the humidity control pump (HHC) has run through. This item is only displayed if the humidity control option (HHC) is installed.

Set PIN




To prevent unauthorised persons making entries on the operating panel, the key pad can be locked using a PIN.

To set a PIN, use the lower **ON/OFF** key to activate the key pad lock. Then press the lower **Plus** or **Minus** key to set a PIN (a number between 0 and 9999).

If the control panel has been locked with a PIN, a small lock symbol appears at the top left of the display.

If you try to press a key while the PIN is active, *LOCKED* appears on the display and you are prompted to enter the PIN. This can be set with the arrow key and confirmed by pressing the **SET** key. If the entry is correct, the lock symbol disappears and the control panel is unlocked.

If no entry is made for a minute, the PIN is activated again and the control panel is locked again.



If the key pad lock is active, this information can be read via the Ethernet interface. In this way, when the device is controlled remotely (e.g. via eve[®]), it can be determined and logged whether the key pad lock is active or not.

Ethernet Connection

Set whether and in which direction data can be sent via the Ethernet interface. The following settings are possible:

- *Read & write*: Send and receive data, i.e. information from the device can be recorded but commands can also be sent to the device (e.g. changes to the setpoints).
- *Read only*: Only receive data, i.e. only data sent from the device can be recorded.
- *OFF*: The Ethernet interface is deactivated; no communication can take place.

If the device is in a network and an IP has already been assigned (manually or via DHCP), the IP address of the device is displayed in the lower area.

Door Alarm

To prevent the door from being left open unintentionally, the device has a door alarm (beeping). This is triggered if the door is left open for longer than the set time. If no parameter was active prior to opening the door, the door alarm is not triggered. The time until the door alarm is triggered can be set in the Setting menu (1 to 10 minutes). If necessary, the door alarm can also be deactivated completely.

To set the period until the door alarm is triggered, use the **ON/OFF** key to activate the door alarm. Then press the lower **Plus** or **Minus** key to set the duration (1 to 10 minutes).

Operation

Set Time

Setting the local time. This is necessary to ensure that the timestamp in the event list is displayed correctly.

To set the time, use the lower **SET** key to select the part of the time (hour or minutes) that is to be changed. Following that, use the lower **Plus** or **Minus** key to set the desired value.

The newly set time does not have to be saved. The time is saved automatically as soon as the menu item is closed using the upper **Plus** or **Minus** key or the Settings menu is closed.

! NOTICE

If the device is switched off, the set time is stored for approx. 7 days. After this time has elapsed, the time is reset again and must be set again.

The time does not adjust automatically when the clock is changed and must be changed manually.

Set Date

Setting the current date. This is necessary to ensure that the correct date is displayed in the event list.

To set the date, use the lower **SET** key to select the part of the date (day, month or year) that is to be changed. Following that, use the lower **Plus** or **Minus** key to set the desired value.

! NOTICE

If the device is switched off, the set date is stored for approx. 7 days. After this time has elapsed, the date is reset again and must be set again.

Set Max. Temperature

Setting the maximum temperature that can be entered as a setpoint.

Set Min. Temperature

Setting the minimum temperature that can be entered as a setpoint.

Set Max. Speed

Setting the maximum rotation speed that can be entered as a setpoint.

Set Brake Power

Setting the braking power with which the shaker drive is stopped when the "Rotation speed" parameter is switched off.

- At brake force level 0 the shaking table is stopped by reducing the rotation speed very slowly.
- At brake force level 1 the shaking table is also controlled but stopped a little less slowly.
- At brake force level 2 a passive brake is activated by switching off the motor.
- At brake force level 3 the motor is short-circuited to stop the shaking table as quickly as possible.



The brake force setting is effective only when the "Rotation speed" parameter is switched off manually, but not when the door is opened. When the door is opened, the shaking table is automatically stopped with the maximum brake force, regardless of which brake force has been set. To activate the brake force setting, always deactivate the "Rotation speed" parameter first, before opening the door.

Illumination

Setting the behaviour of the working light.

- *Auto*: The working light is switched on by pressing any key or when the door is opened. After 2 minutes the working light switches off again automatically.
- *ON*: The working light is switched on permanently.
- *OFF*: The working light is switched off permanently.



The brightness of the display is synchronised with the working light of the device. As soon as the working light is switched off, the brightness of the display is reduced.

Button Sounds

Activating or deactivating the key sound (clicking sound when pressing a key).

Altitude and CO₂

The digital CO₂ sensor GMP251 is pressure-dependent. To achieve precise measuring results, the altitude of the device's location can be set.

Timer

Activating or deactivating the timer function. If the timer function is set to *OFF*, it can no longer be selected by using the **Timer** key.

Operation

7.7 Switching off the Device

NOTICE




Parameters that have not been deactivated before the device is switched off are automatically activated when the device is switched on again. This can damage the device and the cultivation vessels.

- Deactivate all active parameters before switching off the device.
- Do not leave any objects in the incubation chamber when the device is switched off.



The parameter setpoints are stored for approx. one month.

To switch off the device, proceed as follows:

- 1.**  Deactivate all active parameters. You must make sure that, in addition to the rotation speed, parameters that are not visible such as "Temperature", "Humidity" or "CO₂" are also switched off.
- 2.**  Press the power switch of the device.
- 3.**  If the device is not going to be used for an extended period of time, unplug the power plug.

7.8 Behaviour in Case of a Power Interruption

If the power supply to the device is interrupted during a running cultivation process (e.g. by pressing the power switch or in case of a power failure), all parameters and timer setpoints as well as the residual time of the last active timer phase are stored.

If the power supply is restored, the device automatically restarts with the last stored setpoints. If a timer was active prior to the interruption to power supply, the device restarts with the residual time of the last active phase and the setpoints stored for this phase.

INFO: RESTARTED

Device restarted automatically after power loss with saved parameter setpoints.

For your information the *INFO: RESTARTED* message appears on the view box. The message can be confirmed by pressing any key.

8 Rectifying Faults

The following chapter describes possible reasons for faults and how to resolve them.

WARNING


Improper rectification of faults may lead to dangerous situations.

- To prevent life-threatening electric shocks, always switch off the device and disconnect it from the power supply before carrying out any work to find the cause of the fault or to rectify the fault.
- Never remove the covers of the device.
- Damaged parts may only be replaced by an INFORS HT service technician, a licensed dealer or authorised expert personnel.
- Contact the manufacturer in case of faults that cannot be resolved by following the notices below. For service contact details, see page 2.

8.1 Alarm Messages

An alarm (*ALARM*) does not directly affect the process; the device can continue running without any restrictions. Alarms are triggered, for example, if the actual value of a parameter deviates too much from the setpoint or the door is open for too long. Alarms are indicated with the alarm symbol and an acoustic signal. Alarm messages can be confirmed by pressing any key. If an alarm is not confirmed manually, it disappears as soon as the condition that triggered the alarm is no longer met.

8.1.1 Parameter Alarms (*HIGH/LOW*)



A parameter alarm is triggered if the actual value of a parameter deviates too much from the setpoint after a set waiting time. In the example on the left, the temperature is too high. The maximum permissible deviation from the setpoint and the waiting time are set in the factory and cannot be changed.



An alarm is only triggered if the actual value of the parameter does not change for a certain period of time. If there is a fluctuation, the counter for triggering the alarm is reset.


Rectifying Faults

Alarm	Meaning	Deviation from setpoint	Waiting time
<i>Temp HIGH/LOW</i>	Temperature too high/low	$> \pm 1\text{ }^{\circ}\text{C}$	20 min (18 °C to 40 °C)
			75 min (< 18 °C / > 40 °C)
<i>RPM HIGH/LOW</i>	Rotation speed too high/low	$> \pm 10\text{ min}^{-1}$	2 min
<i>CO₂ HIGH/LOW</i>	CO ₂ concentration too high/low	$> \pm 0.5\text{ }%$	15 min
<i>Humidity HIGH/LOW</i>	Humidity is too high/low	$> \pm 5\text{ }%$	15 min

8.1.2 Device-specific Messages

Alarm	Meaning
<i>INFO: RESTARTED</i>	The device has been automatically restarted after a power interruption. For details, see ➔ Chapter 7.8 'Behaviour in Case of a Power Interruption' on page 90.
<i>ALARM: DOOR OPEN</i>	The door has been open for longer than permissible. You can set in the settings menu whether an alarm is to be triggered and after what period of time (1 to 10 minutes).
<i>ALARM: FAN X</i>	<p>The device is equipped with four independent axial fans to circulate the air in the incubation chamber. To prevent the device from stopping if a single fan fails (e.g. due to a blockage or defect), only an alarm is triggered in this case. The device continues to run without restrictions. An error is triggered and the device is stopped only if two or more axial fans fail.</p> <p>As soon as the blockage has been cleared or the defective axial fan has been replaced, the temperature parameter has to be deactivated and then re-activated once. This clears the alarm message.</p>

8.2 Error Messages



An error (*ERROR*) is triggered if there is a technical device fault. The affected parameters are deactivated automatically. Instead of the parameter value, *ERR* appears in red writing. An error is also indicated by an error message as well as an acoustic signal. Errors can be confirmed by pressing the **Select** key.



The faults listed here can often not be resolved by the operator. If an error message is displayed, one of the manufacturer's service technicians often needs to be consulted.

Error message	Description	Solution
<i>ERROR: TEMPERATURE SENSOR</i>	The measured temperature falls outside the permissible range. The temperature sensor is defective.	Contact your local INFORS HT representative.
<i>ERROR: FAN 1-4</i>	At least two of the four axial fans are blocked or defective.	Contact your local INFORS HT representative.
<i>ERROR: MOTOR OVERHEAT</i>	The controller of the motor has overheated because of excessively high rotation speed or excess loading.	<ol style="list-style-type: none"> 1. ➤ Let the motor cool down. 2. ➤ Reduce the load. 3. ➤ Start the device. 4. ➤ If the error message appears again, contact INFORS HT.
<i>ERROR: DRIVE BLOCKED</i>	The drive or the shaking table is blocked.	<ol style="list-style-type: none"> 1. ➤ Remove foreign objects from the incubation chamber, if necessary, dismount the shaking table to do so (➔ chapter 9.2.3, page 103). 2. ➤ If this does not help, contact your local INFORS HT representative.

Rectifying Faults

Error message	Description	Solution
<i>ERROR: DRIVE BELT BROKEN</i>	The drive belt is torn.	Contact your local INFORS HT representative.
<i>ERROR: MOTOR CONTROL</i>	The motor or the controller of the motor is defective.	Contact your local INFORS HT representative.
<i>ERROR: HUMIDITY SENSOR</i>	The humidity sensor is not returning any readings (humidity sensor not connected or defective).	<ol style="list-style-type: none"> 1. → Check and ensure that the sensor is connected correctly to the cable. 2. → If this does not help, contact your local INFORS HT representative.
<i>ERROR: WATER HUMIDIFICATION</i>	The water supply for humidification is interrupted (empty water tank, defective hose or defective pump).	<ol style="list-style-type: none"> 1. → Check and, if appropriate, fill the water tank. 2. → Check the hose line between the water tank and the device. 3. → If this does not help, contact your local INFORS HT representative.
<i>ERROR: HUMIDIFICATION HEATER</i>	The humidity control heater is defective.	Contact your local INFORS HT representative.
<i>ERROR: HUMIDITY HEATER OFF</i>	The temperature sensor or the electronics of humidity control are defective.	Contact your local INFORS HT representative.
<i>ERROR: CO2 SENSOR</i>	The CO ₂ sensor is not returning any readings (CO ₂ sensor not connected or defective).	<ol style="list-style-type: none"> 1. → Check and ensure that the sensor is connected correctly to the cable. 2. → If this does not help, contact your local INFORS HT representative.

Rectifying Faults

Error message	Description	Solution
<i>ERROR: CO2 CONTROL</i>	<p>The CO₂ actual value does not rise (CO₂ supply interrupted, pressure too low or door not closed correctly).</p>	<ol style="list-style-type: none"> 1. → Ensure that the door is closed completely. 2. → Check the CO₂ supply. If appropriate, install a new CO₂ cylinder. 3. → Check inlet pressure and flow rate and increase if necessary. 4. → If this does not help, contact your local INFORS HT representative.
<i>ERROR: EEPROM</i>	<p>The EEPROM has been initialized.</p> <p>The error may occur if there are problems with the EEPROM or if there are problems with one of the internal data buses. Depending on which part of the EEPROM was affected by the error, settings or calibrations of the sensors may have been reset to the factory settings.</p> <p>After the error has occurred, the device can normally continue to be used. Nevertheless, an INFORS HT representative should be contacted to check the device and the settings.</p>	<ol style="list-style-type: none"> 1. → Confirm the error message by pressing the OPTION key. 2. → Check the parameters and the general settings in the settings menu and adjust if necessary. 3. → Contact your local INFORS HT representative to have the other device settings checked.
<i>ERROR: DISPLAY HW</i>	<p>The display unit is defective.</p>	<p>Contact your local INFORS HT representative.</p>

8.3 Fault Tables

The tables below describe potential faults that do not usually trigger an error message on the display or – with a few exceptions – an alarm signal.

Rectifying Faults

General Faults

Fault description	Cause	Remedy	Personnel
After activating the power switch, the display and the power switch do not light up.	Power supply of the device interrupted.	<ul style="list-style-type: none"> ■ Check if the plugs are plugged in correctly. ■ Check the mains connection. 	Operator
	The fuse has triggered.	Change the fuse (→ chapter 8.4, page 99). If the fuses trigger several times, contact your nearest INFORS HT representative.	Operator
The working light does not work.	The working light is deactivated.	Activate the working light (→ ‘Illumination’ on page 89).	Operator
	The lighting element is defective.	Contact your local INFORS HT representative.	INFORS HT service technician or licensed dealer

Faults in Conjunction with the “Rotation Speed” Parameter

Fault description	Cause	Remedy	Personnel
Strong vibrations occur.	The load is distributed unevenly.	Load the tray in the centre. If possible, do not place any heavy weights in the corners of the tray.	Operator
	The rotation speed is too high.	Reduce the rotation speed.	Operator
	The device is not standing straight.	Level the table or the device (adjustable foot on the base).	INFORS HT service technician or licensed dealer
	The substrate is too weak.	Place the device on a stable substrate.	INFORS HT service technician or licensed dealer

Rectifying Faults

Faults in Conjunction with the “Temperature” Parameter

Fault description	Cause	Remedy	Personnel
The temperature fails to reach the desired set-point.	The door is not closed completely.	Close door completely.	Operator
	No cooling is available and the difference to the ambient temperature is too small.	Increase the setpoint or equip the device with cooling.	Operator
	Error during temperature measurement.	Check whether the Pt100 sensor is working properly. In case of a defect, contact your local INFORS HT representative.	Operator
	Fans are defective, air circulation in the incubation chamber is therefore insufficient.	Contact your local INFORS HT representative.	INFORS HT service technician or licensed dealer
Poor cooling performance. The desired set-point cannot be reached even though the cooling unit is in operation.	The door is not closed completely.	Close door completely.	Operator
	The room temperature is too high. IMPORTANT: The room temperature refers to the temperature directly on the device. This can be significantly higher than the temperature in other parts of the room.	<ol style="list-style-type: none"> 1. → Reduce the room temperature. 2. → Use a fan to improve air circulation. 3. → Move the device. 	Operator INFORS HT service technician or licensed dealer
	Other devices with strong heat radiation are located in the immediate vicinity of the device (e.g. ultra-low freezers or refrigerated centrifuges).	<ol style="list-style-type: none"> 1. → Use a fan to improve air circulation. 2. → Place a barrier between the devices. 3. → Move the device. 	Operator INFORS HT service technician or licensed dealer
	A barrier in the room prevents circulation of cold air.	<ol style="list-style-type: none"> 1. → Remove the barrier. 2. → Move the device. 	Operator INFORS HT service technician or licensed dealer

Rectifying Faults

Fault description	Cause	Remedy	Personnel
Poor cooling performance. The desired set-point cannot be reached even though the cooling unit is in operation.	The room temperature is not constant (e.g. because the air conditioning is turned down on the weekend).	Ensure that the room temperature is constant.	Operator
	Required minimum distances for air circulation are not observed. The device has been pushed back against the wall.	Move the device to ensure that heat can escape and heat does not accumulate.	INFORS HT service technician or licensed dealer
	The device was positioned under a table without air vent.	Move the device.	INFORS HT service technician or licensed dealer
	The air vents are covered.	Remove all objects that cover air vents.	Operator



Re-measuring the temperature only provides reliable information when using calibrated measuring tools, and only for measurements at points specified by INFORS HT. Measurements taken at undefined points in the housing will not produce any usable data.

For information about temperature measuring, contact your local INFORS HT representative.

Faults in Conjunction with the “CO₂ Concentration” Parameter

Fault description	Cause	Remedy	Personnel
CO ₂ concentration too low (deviation > 1%).	CO ₂ cylinder is empty.	Install new CO ₂ cylinder.	Operator
	Inlet pressure or flow too low.	Increase inlet pressure or flow.	Operator
	CO ₂ valve is closed or blocked.	Contact your local INFORS HT representative.	INFORS HT service technician or licensed dealer
CO ₂ concentration too high (deviation < 1%).	CO ₂ inlet pressure is too high.	Reduce the inlet pressure.	Operator
The CO ₂ value is fluctuating, the actual value is not constant	Inlet pressure or flow too high.	Decrease inlet pressure or flow.	Operator



Faults in Conjunction with the “Humidity” Parameter

Fault description	Cause	Remedy	Personnel
The “Humidity” parameter was deactivated automatically.	Transfer error of the humidity sensor or temperature sensor.	Switch the device off and then on again.	Operator
	Inlet pressure is too high.	Reduce inlet pressure (max. 2 bar).	Operator
	The humidity control is defective.	Contact your local INFORS HT representative.	INFORS HT service technician or licensed dealer

8.4 Replacing Device Fuses

i The device fuses may only be replaced by fuses of the same rating. For information on the requirements regarding fuses, see → Chapter 12.2.3 ‘Electrical Connection and Power Values’ on page 110.

To replace a defective device fuse, proceed as follows:



- 1.** → Turn off the device and pull out the power plug.
- 2.** → Release the slot for the device fuses next to the mains connection by pressing together the two flaps and pulling out at the same time.
- 3.** → Remove the defective device fuse.
- 4.** → Insert a new device fuse with the correct number of Amperes.
- 5.** → Push the plug as far back in the opening as possible until it snaps in.
- 6.** → Restore the power supply to the device.

Rectifying Faults


8.5 Returning for Repair

The provider must return the device or the faulty component part(s) to the manufacturer if, after consulting the service department of the local dealer or the manufacturer, on-site diagnosis and/or repair is not possible.



If the device, component or accessory has to be returned to the manufacturer for repair, a legally compliant declaration of decontamination is required for the safety of all parties involved and to comply with legal requirements (→ Chapter 2.10 'Declaration of Decontamination' on page 26).

9 Cleaning and Maintenance

 WARNING

Improper cleaning and maintenance of the device may lead to dangerous situations.

- To prevent life-threatening electric shocks, always switch off the device and disconnect it from the power supply before carrying out any maintenance or cleaning.
- Never remove the covers of the device.
- Damaged parts may only be replaced by an INFORS HT service technician, a licensed dealer or authorised expert personnel.

9.1 Maintenance

The device requires hardly any maintenance. This reduces the running costs to certain regular checks and cleaning. The following table describes the maintenance work that is required to ensure optimum, fault-free operation.

If increased wear is detected during regular checks, the required maintenance intervals must be shorted in accordance with the actual signs of wear. Keep in mind that various media or gases have more or less corrosive effects on the metal parts. When using particularly aggressive substances, more frequent checks are required to maintain smooth device operation.

Contact the manufacturer if you have questions about maintenance work and intervals, see service contact details on page 2.

Interval	Maintenance work	Personnel
Prior to each use	Check hoses and power cables for damage; replace if necessary.	Operator
	Check that hoses (water, CO ₂) are connected tightly.	Operator
	Check all seals on the device, especially on the door, and replace if necessary.	Operator
	Check whether the interior working light works; have lighting elements replaced if necessary.	Operator
After each use	Clean the device; if necessary, disinfect thoroughly.	Operator

Cleaning and Maintenance

Interval	Maintenance work	Personnel
Annually	If you are using humidity and CO ₂ sensors, have these calibrated at least once a year to ensure measuring results remain accurate.	Technician
	When using the optional Hygienic Humidity Control (HHC): Have maintenance performed annually. This includes replacing the air filter and the seal as well as cleaning the evaporator chamber.	INFORS HT service technician or licensed dealer

9.2 Cleaning and Disinfection

If substances, especially substances hazardous to health, have been spilled on or in the device, the device must be thoroughly cleaned and disinfected. The device should also be routinely cleaned and disinfected at regular intervals to ensure trouble-free operation.

If you are not sure about the compatibility of cleaning agents and disinfectants, contact INFORS HT.

! NOTICE

Insufficient cleaning and disinfection can lead to damage to cultures due to contamination.

9.2.1 Cleaning the Device

Detergent

Mild detergents, e.g. dishwashing liquid or neutral cleaning agents, are suitable for all surfaces:

- Exterior surfaces of the casing
- Front window
- Interior surfaces of the casing
- Steel plate covers
- Table
- Trays (incl. clamps and other holders)

! NOTICE

Aggressive detergents, solvents and abrasive cleaning utensils (hard sponges, brushes) can scratch surfaces, damage the device and impair its function.

Cleaning and Maintenance

Notices on Cleaning

To clean the surfaces, use a soft cloth, ideally lint-free. This applies in particular to the front window. Disinfect using commercially available disinfectant if necessary.

Spray

When cleaning the base tray, only use a wet cloth, never pour water into the tray. Make sure that no water splashes into the bearings. After cleaning the device, especially the interior and the base tray, dry it with a cloth.

Air Vents and Fan

Over time, dust and other contaminants can accumulate on the vents and fans and other exposed areas. This may affect the operation of the device, for example, if the air circulation for cooling the electronic components is restricted. Dust and other impurities can be carefully removed with a damp cloth or with a vacuum cleaner.

9.2.2 Disinfecting the Device

Only use quaternary ammonium compounds for wipe-down disinfection. As a tried and tested disinfectant, we recommend Fermacidal D2.

! NOTICE




Heat (temperatures above 80 °C), aggressive disinfectants such as chlorine bleach and UVC radiation can damage the device and significantly limit the function and service life of the device.

We recommend against using UV lamps for disinfection of the device because the UV rays can massively damage the housing in case of multiple applications.


9.2.3 Cleaning and Disinfecting the Base Tray

If glass is broken or large amounts of liquid are spilled, liquid may accumulate underneath the shaking table. To drain leaked liquids, the device has a discharge outlet on the left side. In order to be able to clean the base tray in case of glass breakage or other contamination by culture liquids, the shaking table can also be detached from the counterweight and removed. Proceed as follows:

Removing the Table

1.  Open the device door all the way.
2.  Remove the tray.
3.  Switch off the power switch and pull out the power plug.


Cleaning and Maintenance



Cleaning the Base Tray

4. ➤ Remove the four screws (hexalobular M6x16, Torx T30) in the centre of the table.
5. ➤ Carefully lift the table vertically.

Disinfecting the Base Tray



6. ➤ Clean the base tray with a mild cleaning agent. Larger quantities of liquid can be drained off via the discharge outlet on the left side.


To completely clean the base tray, the black counterweight that is underneath the table can be moved slightly by hand.
7. ➤ Thoroughly dry the base tray using paper towels.
8. ➤ Carefully apply disinfectant to the area of the base tray coloured in the graphic and let it take effect.

! NOTICE

The disinfectant may only be placed in the base tray. It must not come into contact with the metal parts of the shaking mechanism or the components of the upper part of the device.

In particular, all ball bearings of the shaker drive must not come into contact with disinfectants!

Fitting the Table



9. ➤ After the exposure time (see manufacturer's instructions), remove the disinfectant (wipe up).
10. ➤ Wipe or rinse with (sterile) water to remove all residues.
11. ➤ Align the flange in the centre of the unit (1) in such a way that the four threaded holes are exactly on the vertical and horizontal axis.
12. ➤ Put down the table as straight as possible, parallel to the front edge of the device and lower it down vertically from above. In doing so, ensure that the four ball bearings are in the trays underneath the table.
13. ➤ Slightly move the table to cover the thread holes in the flange with the drilling in the table.
14. ➤ Insert the four screws crosswise (order: back, front, right, left) and tighten.



If the screws are lost or damaged, only replace them with original screws (hexalobular M6x16).

10 Transport and Storage

Inbound delivery and transport to the assembly location are performed only by INFORS HT employees or by persons authorised by INFORS HT. Nonetheless it is possible that the provider's personnel is entrusted with transport tasks in the context of on-site transport. In this case, observe the following notes.

10.1 Transport

WARNING

Improper transport, use of incorrect auxiliary tools and careless handling of the device may lead to injuries and significant damage to property.

When transporting the device, observe the following:

- Prior to moving the device, transport fasteners (rubber wedges) must be inserted to prevent uncontrolled movements of the table.
- Always work in pairs and use suitable auxiliary equipment when transporting the device.
- Especially when using auxiliary tools, it is important to keep in mind that the device's centre of gravity is not in the middle.

10.2 Storage

- Decontaminate, thoroughly clean and dry the device every time before placing it in storage.
- Store the device and its components clean, dry and protected against dust, dirt and liquids.
- Store the device and its components in a cool place with low humidity but protected against frost.
 - Storage temperature: 10 °C to 35 °C.
 - Relative humidity, non-condensing: 10 % to 85 %.
- Protect the device from aggressive media, direct sunlight and vibrations.

Disassembly and Disposal

11 Disassembly and Disposal

The device must be disassembled and disposed of in an environmentally-friendly manner if it is not in use anymore.



If the device is to be returned to the manufacturer for disassembly and disposal, a legally compliant declaration of decontamination is required for the safety of all parties involved and to comply with legal requirements (→ Chapter 2.10 'Declaration of Decontamination' on page 26).

11.1 Disassembly

Prior to disassembly:

- Switch off the device and secure against reactivation.
- Physically disconnect the main energy supply from the device and wait for any components to fully discharge.
- Remove and dispose of all operating and auxiliary materials as well as remaining processing materials in an environmental acceptable manner.

Clean and disassemble component parts professionally with regard to any local regulations concerning employment and environmental protection. If possible, separate materials.

11.2 Disposal

Recycle disassembled components if no agreement is made concerning reclaim or disposal.

- Scrap metals.
- Recycle plastic components.
- Sort and dispose of the remaining components according their material composition.

WARNING

Electronic waste, electronic components, lubricants or other auxiliary materials/supplies are subject to hazardous waste regulations and may only be disposed of by registered specialist disposal firms.

Disassembly and Disposal


For disposal, the system units must be disassembled and dismantled into individual material groups. These materials must be disposed of according to the applicable national and local legislation. Local authorities or specialist disposal firms can provide information regarding environmentally acceptable disposal.

If no special arrangements have been made for return, Infors devices with the required declaration of decontamination can be sent back to the manufacturer for disposal.

Technical Data

12 Technical Data

12.1 Dimension Drawings



- 1 Discharge outlet (internal thread G1/4")
- 2 Analogue output
- 3 CO₂ control (hose nozzle DN04 / 0.4 bar to 0.6 bar)
- 4 Hygienic humidity control (HHC) (UNF 1/4-28 for hoses 1/8" / max. 2.0 bar)
- 5 Cable pass-through

12.2 Specifications of the Basic Unit

12.2.1 Weight

Data	Value	Unit
Single unit (25 mm throw)	75	kg
Single unit (50 mm throw)	77	kg
Base 13 cm	7.5	kg

12.2.2 Dimensions

Exterior Dimensions (without Options)

Data	Value	Unit
Width	800	mm
Depth (door closed)	625	mm
Depth (door open)	1389	mm
Height (with rubber feet)	700	mm
Height (with 130 mm base)	812	mm
Height (2 stack with base)	1495	mm

Interior Dimensions (Incubation Chamber)

Data	Value	Unit
Width	570	mm
Depth	528	mm
Height	508	mm

Floor space and required space

Data	Value	Unit
Floor space ¹⁾	ca. 1.0 x 0.7	m
Space required ²⁾	ca. 1.0 x 1.5	m

¹⁾ incl. min. distance of 80 mm on the side of and behind the device

²⁾ incl. operating space when door is open

Technical Data

12.2.3 Electrical Connection and Power Values

Type 230 V

Data	Value	Unit
Voltage	230	VAC
Frequency	50/60	Hz
Max. power consumption	650	W
Max. current consumption	2.8	A
Device fuses (two 5 x 20 mm fuses, time lag)	6.3	A
Oversvoltage category	II	

Type 115 V

Data	Value	Unit
Voltage	115	VAC
Frequency	60	Hz
Max. power consumption	650	W
Max. current consumption	5.6	A
Device fuses (two 5 x 20 mm fuses, time lag)	6.3	A
Oversvoltage category	II	



The power and current consumption data apply to a fully equipped device with cooling, humidity control and CO₂ control.

12.2.4 Connections and Interfaces

Alarm Connection

Data	Value
Type	Stereo jack, 3.5 mm
Relay	Rectifier NO / NC max. 1A 34V AC/DC

Technical Data

Ethernet Interface

Data	Value
Type	RJ45
Data transfer	10/100 Mbps Ethernet

Discharge Outlet

Data	Value	Unit
Hose nozzle	1/4	Inch
Hose diameter	10	mm

12.2.5 Materials

Data	Value
Housing	Polyurethane (PUR-IHS) with flame retardant
Door	PUR-IHS, safety glass
Cover plate temperature control	Stainless steel (AISI 304)
Shaking table	Aluminium, anodised


12.2.6 Emissions

Data	Value	Unit
Sound pressure	35	dB(C)

Technical Data

12.2.7 Operating Conditions

Data	Value	Unit
Temperature range	10 to 32	°C
Relative humidity, non-condensing	10 to 85	%
Altitude operating location	max. 2000	M above sea level
Pollution degree as per EN 61010-1	2	
Maximum load	12	kg
Min. distance from walls, ceilings and other devices	80	mm

 The specified temperature range refers to the temperature directly on the device. In case of heat build-up due to insufficient ventilation, the temperatures on the device can be significantly higher than the room temperature.

12.2.8 Fire Protection Class and Protection Type

Data	Value
Fire protection class as per DIN 4102	B1
IP protection type as per DIN EN 60529	IP20

12.2.9 Operating and Auxiliary Materials

! NOTICE

Using the wrong auxiliary materials can result in significant damage to property.

Only use the auxiliary materials prescribed by the manufacturer in accordance with the table below.

Technical Data

Specification	Approved/applied products
Refrigerant (cooling compressor)	R134a
Cleaning agent	<ul style="list-style-type: none"> ■ Mild neutral cleaning agent ■ Dishwashing detergent
Disinfectants	Quaternary ammonium compounds


12.3 Specifications of the Standard Parameters

12.3.1 Rotation Speed Parameter (Shaker Drive)

Data	Value
Direction of rotation	Clockwise

Data	Value	Unit
Throw	25 or 50	mm
Increment	1	min ⁻¹
Control precision (at maximum rotation speed, full scale)	± 1	%

Rotation Speeds



The actual rotation speed that can be achieved depends on a variety of factors, such as loading, vessel type (e.g. flasks with baffles) and the fixtures used (e.g. clamps or "Sticky Stuff" adhesive matting).

The minimum rotation speed for all unit variants is 20 min⁻¹. The maximum rotation speed of an equipment unit depends on the throw and the position of the unit in the stack:

Single unit	25 mm	50 mm
	400 min ⁻¹	350 min ⁻¹
Two units stacked	25 mm	50 mm
Top unit	400 min ⁻¹	300 min ⁻¹

Technical Data

Two units stacked	25 mm	50 mm
Bottom unit	400 min ⁻¹	350 min ⁻¹

Recommended Rotation Speeds

The following guidelines for the maximum rotation speeds are specified to avoid damage. As such, they must be observed, though other restrictions (e.g. tray with Sticky Stuff) must also be taken into account.

Single unit			
Load	Filling	25 mm throw	50 mm throw
12 x 500 ml Erlenmeyer w/o baffles	1/3	400 min ⁻¹	340 min ⁻¹
8 x 1000 ml Erlenmeyer w/o baffles	1/3	380 min ⁻¹	310 min ⁻¹
5 x 2000 ml Erlenmeyer w/o baffles	1/3	290 min ⁻¹	240 min ⁻¹
3 x 5000 ml Erlenmeyer w/o baffles	1/3	260 min ⁻¹	240 min ⁻¹
4 x 2500 ml Ultra-Yield (plastic)	1000 ml	350 min ⁻¹	280 min ⁻¹
3 x 5000 mL Optimum Growth (plastic) (on Sticky Stuff)	2500 ml	240 min ⁻¹	230 min ⁻¹

Two units stacked			
Load	Filling	25 mm throw	50 mm throw
12 x 500 ml Erlenmeyer w/o baffles	1/3	400 min ⁻¹	310 min ⁻¹
8 x 1000 ml Erlenmeyer w/o baffles	1/3	360 min ⁻¹	300 min ⁻¹
5 x 2000 ml Erlenmeyer w/o baffles	1/3	270 min ⁻¹	220 min ⁻¹
3 x 5000 ml Erlenmeyer w/o baffles	1/3	230 min ⁻¹	220 min ⁻¹
4 x 2500 ml Ultra-Yield (plastic)	1000 ml	300 min ⁻¹	240 min ⁻¹
3 x 5000 mL Optimum Growth (plastic) (on Sticky Stuff)	2500 ml	210 min ⁻¹	200 min ⁻¹

Technical Data



For the bottom unit of a stack, the values for the maximum rotation speed stated for individual units apply.

Due to the leverage effect, reduced maximum permissible rotation speeds apply to the top unit. The values for the top unit apply irrespective of the throw of the unit at the bottom.

All this information is intended solely as a guideline (not guaranteed). Depending on the load, higher rotation speeds are possible; in this case, the speed should be increased slowly. In such cases, the user is responsible for determining the maximum possible speed based on the vibrations and the vessel holders (the clamps may need to be secured) and communicating them. If vibrations occur, reduce the rotation speed until the device runs smoothly. Alternatively, increase or reduce the rotation speed until the device runs smoothly.

Maximal Shaking Speeds with Sticky Stuff

For a detailed description of the maximum permissible rotation speeds when using Sticky Stuff adhesive matting, ➔ Chapter 5.1.6 'Tray with Sticky Stuff' on page 55.

12.3.2 Temperature Parameter

Measurement/Control


Data	Value
Control	PID controller
Sensor type	PT100 class 1/3 DIN B

Data	Value	Unit
Setting range	4.0 to 65.0	°C
Increment	0.1	°C
Control precision 4 °C to 50 °C	± 0.3	°C
Control precision > 50 °C	± 0.5	°C

Technical Data

Information on Temperatures that can Actually be Reached

The temperature range limited by the measuring and control unit ranges from 4 °C to 65 °C. The temperatures that can actually be reached depend on a variety of factors, such as the ambient temperature, the ventilation and the temperature of the other devices in the stack. As such, the following guideline values (no guarantees) only apply under optimal conditions. In order to reach these guideline values, the device must be free-standing and the heat it generates must be able to dissipate unobstructed.



The specified ambient temperature refers to the temperature directly on the device. In case of heat build-up due to insufficient ventilation, the temperatures on the device can be significantly higher than the room temperature.

Configuration	Lowest possible temperature
Single unit without cooling	5 °C above ambient temperature
Single unit with cooling	16 °C below ambient temperature

12.3.3 Ideal Loading Weights

The ideal load for a tray falls into the following ranges (mass incl. tray, clamps, flasks and filling):

Throw	Ideal load
25 mm	6 – 11 kg
50 mm	7 – 10 kg

With the above-mentioned load, the device is ideally balanced. Both higher and lower loads can cause an imbalance, which can result in vibrations at higher rotation speeds. If vibrations occur, the tray can be weighted down with additional flasks filled with water until the optimum mass is reached.

12.4 Specifications of the Options

12.4.1 Cooling

Electric Specifications

Description	230 V/ 50 Hz	230 V/ 60 Hz	115 V/ 60 Hz
Power consumption of the compressor	173 W	196 W	146 W
Current consumption	0.93 A	1.12 A	0.78 A

Various

Data	Value	Unit
Cooling power ¹⁾	200 to 230	W
Additional mass	9.0	kg

¹⁾Cooling capacity at temperature of the cooling medium = 20 °C (20 °C ambient temperature)

12.4.2 Hygienic Humidity Control (HHC)

Housing Dimensions

Data	Value	Unit
Height	340	mm
Depth	80	mm
Width	200	mm

Technical Data

Miscellaneous

Data	Value
Sensor type	EE071/EE072 HCT01

Data	Value	Unit
Additional mass	3	kg
Water consumption ¹⁾	5	g/h
Temperature range for use ²⁾	28 to 40	°C
Heating time of the unit	approx. 5	min

¹⁾ At an ambient temperature of up to 20 °C and a temperature of 37 °C and relative humidity of 75 % in the incubation chamber.

²⁾ Temperature in the incubation chamber at which functionality can be guaranteed.

Control

Data	Value	Unit
Setting range	20 to 85	% rH
Increment	1	% rH
Control precision	± 3	% rH

Humidity that can be Reached

Data	Value	Unit
Max. humidity without condensation (at 37 °C in the incubation chamber, 20 °C / 25 °C ambient temp.)	75	% rH
Min. humidity (at 30 °C in the incubation chamber, 25 °C ambient temp.)	70	% rH
Min. humidity (at 40 °C in the incubation chamber, 25 °C ambient temp.)	50	% rH



The humidity in the incubation chamber can never be less than the humidity of the ambient air.

Technical Data

Electric Specifications

Specification	Type 230 V	Type 115 V
Max. power consumption	125 W	125 W

Connection/Water Quality

Data	Value	Unit
Connection (hose Ø) <small>(UNF 1/4-28 for hoses 1/8")</small>	3.2	mm
Input pressure	-0.15 to 2	bar
Water hardness (CaCO ₃ equivalent)	< 0.01	mmol/L
Dissolved solids	< 10	mg/L

! NOTICE

Using tap water can quickly lead to limescale in the vaporiser of the humidification unit, which would affect correct functioning.

Adding detergents, disinfectants or similar chemicals to the water for the hygienic humidity control can damage the device. Only use water without additions, in accordance to the specification.

For an optimal operation, reverse osmosis water with a conductivity of approx. 5 µS/cm is recommended. Ultra-pure water or WFI (water for injection purposes) are also permissible.

12.4.3 CO₂ Control

Connection Data

Data	Value	Unit
Connection (hose Ø)	3 to 4	mm
Input pressure	0.4 to 0.6	bar

Technical Data

Miscellaneous

Data	Value	Unit
Sensor type	GMP251	
Additional mass	0.5	kg
Gas consumption (air vent open, at 5 % CO ₂)	approx. 2	L/h
Gas consumption (air vent open, at 10 % CO ₂)	approx. 3.5	L/h

Control

Data	Value	Unit
Control range	0.1 to 20	% CO ₂
Increment	0.1	% CO ₂
Control precision (at 1013 hPa, 20 °C to 40 °C, 0 to 5 % CO ₂)	0.5	% CO ₂
Control precision (at 1013 hPa, 20 °C to 40 °C, 5 to 10 % CO ₂)	0.6	% CO ₂
Control precision (at 1013 hPa, 20 °C to 40 °C, 10 to 15 % CO ₂)	0.7	% CO ₂
Control precision (at 1013 hPa, 20 °C to 40 °C, 15 to 20 % CO ₂)	0.8	% CO ₂

13 EU Declaration of Conformity

EU-Konformitätserklärung

EU-Declaration of conformity

Déclaration UE de conformité

INFORS HT

Infors AG, Headoffice, Switzerland
Rittergasse 27, CH-4103 Bottmingen
T +41 (0)61 425 77 00
info@infors-ht.com, www.infors-ht.com

Hersteller
Manufacturer
Fabricant

Infors AG
Rittergasse 27
CH-4103 Bottmingen

Bezeichnung
Designation
Désignation

Inkubationsschüttler
Incubation shaker
Incubateur agité

Typ
Type
Type

Minitron

Ab Release
From release
A partir du version

2.1

Ab Seriennummer
From serial number
A partir du numéro de série

S-000129923

Dieses Gerät entspricht den grundlegenden Anforderungen der Richtlinien

This device is in compliance with the essential requirements of directives

Cet appareil est conforme aux exigences essentielles des directives

Maschinenrichtlinie 2006/42/EG

Directive on machinery 2006/42/EC

Directive relative aux machines 2006/42/CE

EMV-Richtlinie 2014/30/EU

EMC directive 2014/30/EU

Directive CEM 2014/30/UE

RoHS-Richtlinie 2011/65/EU

RoHS directive 2011/65/EU

Directive RoHS 2011/65/UE

Aussteller
Issuer
Editeur

Konformitätsbeauftragter
Representative for conformity
Responsable de la conformité



R. Winkler
(COO)

Bottmingen, 23.Aug.2022

Ort, Datum
Place, date
Lieu, date

14 Index

A

Accessories.....	48
box for microtitre plates.....	60
eve.....	65
Sticky Stuff.....	55
tray with clamping assembly.....	52
tray with pin holders.....	51
tray with sliding bars.....	54
tray with steel clamps.....	50
universal table tray.....	49
Activating/deactivating the key pad lock.....	87
Activating/deactivating the PIN.....	87
Admin mode.....	85
Air vent.....	32
Air vents.....	31
ALARM.....	91
Alarm connection	
contacts.....	29
position.....	29
specifications.....	110
Alarm messages	
DOOR OPEN.....	92
FAN.....	92
parameter-specific.....	91
Allowed cultivation vessels.....	19
Ambient temperature.....	112
Analogue output	
connection assignment.....	44
functional description.....	44
Auxiliary materials.....	112
Axial fan.....	28

B

Base, 13 cm	
function.....	33
levelling.....	33
Box for microtitre plates	
mount.....	72
overview.....	60

C

Cable pass-through	
position.....	45
use.....	46
Changing locations.....	66
Clamps	
mount.....	72
plastic.....	59
stainless steel.....	59

Cleaning

base tray.....	103
basic unit.....	102
Sticky Stuff.....	56

Cleaning agent.....	112
---------------------	-----

CO₂ control

connecting.....	42
error messages.....	93
faults.....	98
functional description.....	42
operating.....	43
specification.....	119

CO₂ sensor

position.....	42
specification.....	120

Commissioning.....	66
--------------------	----

Conditions

at the storage location.....	105
------------------------------	-----

Connection

CO ₂ control.....	42
Ethernet.....	30
external alarm.....	29
humidity control.....	40
power supply.....	29
USB.....	30

Connection values, electrical.....	110
------------------------------------	-----

Cooling

functional description.....	37
operating.....	37
refrigerant.....	112
specifications.....	117

Cooling liquids.....	112
----------------------	-----

Cultivation vessels.....	19
--------------------------	----

D

Declaration of decontamination.....	26
-------------------------------------	----

Decommissioning.....	90
----------------------	----

Detergent.....	102
----------------	-----

Device

cleaning.....	102
deactivate.....	90
disinfect.....	103
dismantling.....	106
dispose.....	106
install.....	66
loading.....	71, 74
maintain.....	101
positioning.....	67
switch on.....	70
transport.....	105

Index

Device fuses		
position.....	24	
replace.....	99	
specification.....	110	
Device identification.....	36	
Device information.....	86	
Device settings.....	85	
Dimension drawings.....	108	
Dimensions.....	109	
Disassembly.....	106	
Discharge outlet.....	31	
specifications.....	111	
Disinfectants.....	112	
Disinfection.....	103	
Display elements.....	15	
Display IP address.....	84	
Disposal.....	106	
Distances.....	67	
Door alarm.....	87	
Door heating.....	39	
Door lock.....	70	
Door monitoring.....	24	
E		
Electric connection values.....	110	
Emergency shut-off.....	35	
Emissions.....	111	
Environmental conditions		
installation location.....	66, 112	
storage.....	105	
Erlenmeyer flasks, requirements.....	19	
ERROR.....	93	
Error messages.....	93	
Ethernet interface		
configure.....	87	
position.....	30	
specifications.....	111	
use.....	83	
eve.....	65	
Event list.....	86	
Exterior dimensions.....	109	
EXTERNAL ALARM.....	29	
F		
Fail failure.....	92	
Fan.....	28	
Fault messages.....	93	
Faults.....	91	
CO ₂ control.....	98	
general faults.....	96	
Hygienic Humidity Control.....	99	
shaker drive.....	96	
temperature control.....	97	
Fernbach flasks, requirements.....	19	
Fire protection class.....	112	
Firmware version.....	86	
Flasks.....	19	
Functional description		
analogue output.....	44	
CO ₂ control.....	42	
cooling.....	37	
Hygienic Humidity Control (HHC).....	38	
shaking.....	27	
temperature control.....	28	
Fuses		
position.....	24	
replace.....	99	
specification.....	110	
H		
HEAT.....	40	
Height above sea level.....	89	
HHC.....	38	
HIGH.....	91	
Holders		
mount.....	72	
overview.....	58	
screw sizes.....	73	
Hose pass-through		
position.....	45	
use.....	46	
Humidification.....	38	
Humidity sensor		
position.....	38	
specification.....	118	
Hygienic Humidity Control		
connecting.....	40	
error messages.....	93	
faults.....	99	
minimum distances.....	68	
operating.....	40	
overview.....	38	
specification.....	117	
water quality.....	119	
I		
Identification of the throw.....	36	
Identification plate.....	36	
Incorrect use.....	18	
Info.....	86	
Initial commissioning.....	66	
Installation.....	66	
Installation location.....	66	

Intended use.....	18	O	
Interfaces.....	110	ON/OFF key.....	14
Interior dimensions.....	109	Opening the door.....	70
Interior lighting.....	32	Operating conditions.....	66, 112
configure.....	89	Operating elements.....	13
Interrupted power supply.....	90	Operating hours.....	86
IP address.....	87	Operating panel	
K		display elements.....	15
Keys.....	13	operating elements.....	13
L		overview.....	35
Levelling.....	33	Operation	
Lighting		activating parameters.....	75
configure.....	89	CO ₂ control.....	43
position.....	32	cooling.....	37
Limit		deactivating the parameters.....	76
rotation speed.....	88	setting the parameter setpoint.....	75
temperature.....	88	switching off the device.....	90
Load capacity.....	116	switching on the device.....	70
Loading.....	71, 74	timer.....	76
LOW.....	91	Operator.....	20
M		Option function.....	85
Main switch.....	35	OPTION key.....	14
Mains connection.....	29	Options	
Maintenance.....	101	analogue output.....	44
Maintenance plan.....	101	CO ₂ control.....	42
Mass.....	109	cooling.....	37
Materials.....	111	darkening.....	44
Maximum rotation speeds.....	113	Hygienic Humidity Control (HHC).....	38
with box for microtitre plates.....	62	removable shelf.....	43
with Sticky Stuff.....	58	Overheating shut-down.....	24
Messages		Overview	
ALARM.....	91	accessories.....	48
ERROR.....	93	components.....	9
HEAT.....	40	display and operating elements.....	12
HIGH.....	91	parameters.....	11
RESTARTED.....	90	timer function.....	76
Microtitre box		P	
mount.....	72	Parameter	
overview.....	60	deactivate.....	76
Minimum distances.....	67	setting the setpoint.....	75
Misuse.....	18	switching on.....	75
Modbus TCP gateway.....	63	Power supply	
Motor		mains connection.....	29
operating hours.....	86	requirements.....	67
specification.....	113	specification.....	110
		Power switch.....	35
		Profibus DP gateway.....	63
		Protection classes.....	18
		Protection type.....	112
		Provider.....	21
		Provider obligations.....	22

Index

Pt100	
position.....	28
specification.....	115
Purpose of use.....	18
Q	
Quickload spacer.....	51
R	
Rack.....	32
Rating plate.....	36
Refrigerant.....	112
Removable shelf.....	43
Requirements	
at the installation site.....	66
Requirements for qualified personnel.....	20
Responsibility of the provider.....	22
RESTARTED.....	90
Ring spacer.....	51
Risk classes.....	18
Room temperature.....	112
Rotation speeds.....	113
setting the upper limit.....	88
with box for microtitre plates.....	62
with Sticky Stuff.....	58
Rubber feet.....	33
S	
Safety features.....	24
Screw sizes	
holders.....	73
shaking table.....	103
Sensor	
CO ₂	42, 120
humidity.....	38, 118
Pt100.....	28, 115
Serial number.....	36
SET key.....	14
Setpoint	
reachable, temperature.....	116
setting.....	75
SETPPOINT.....	75
Setting the brake power of the shaking table.....	89
Setting the date.....	88
Setting the time.....	88
Settings menu.....	85
Setup.....	85
Shaker drive	
error messages.....	93
faults.....	96
functional description.....	27
specification.....	113
Shaking table	
dismantling.....	103
mounting.....	103
overview.....	27
screw size.....	103
setting the brake power.....	89
stop automatically.....	70
Shaking throw	
marking.....	36
shaker drive.....	113
Shelf.....	43
Sound pressure.....	111
Specification	
base unit.....	109
CO ₂ control.....	119
CO ₂ sensor.....	120
cooling.....	117
cultivation vessels.....	19
heating.....	115
humidity sensor.....	118
Hygienic Humidity Control.....	117
shaker drive.....	113
ventilation.....	115
Status information.....	86
Steam humidification.....	38
Sticky Stuff	
maximum rotation speeds.....	58
overview.....	55
Sticky Stuff adhesive matting.....	55
Storage.....	105
Structure.....	9
Substructure	
base, 13 cm.....	33
rubber feet.....	33
Switch on.....	70
Switching key sound on/off.....	89
Switching off.....	90
Symbols	
on the device.....	25
on the operating panel.....	15
T	
Technician.....	21
Temperature control	
error messages.....	93
faults.....	97
functional description.....	28
setting the lower limit.....	88
setting the upper limit.....	88
specification.....	115
temperatures that can be reached.....	116

Temperature sensor
 position.....28
 specification.....115

Test tube holder
 mount.....72
 overview.....60

Throw.....36, 113

Timer function
 acknowledging an alarm.....80
 cancel.....82
 changing the setpoints.....81
 cyclic change.....78
 interrupted power supply.....90
 one-time change.....77
 programme.....78
 starting.....80

Transport.....105

Tray
 can be equipped freely.....49
 insert.....71
 mount the holders.....72
 remove.....71
 with clamping assembly.....52
 with pin holders.....51
 with sliding bars.....54
 with steel clamps.....50
 with Sticky Stuff.....55

Tray lock.....71

U

Universal table tray.....49
 USB connection.....30

V

Ventilation opening.....32
 Vibrations.....96

W

Water quality
 Hygienic Humidity Control.....119

Weight.....109
 Working light.....32

Digitize your bioprocesses

The platform software for your bioprocesses



eve® – the Bioprocess Platform Software

Able to do more than just plan, control and analyze your bioprocesses, eve® software integrates workflows, devices, bioprocess information and big data in a platform that lets you organize your projects in the cloud, no matter how complex they are.

Learn more at www.infors-ht.com/eve